


Installation and Operating Instructions

# 96% AFUE Condensing Gas Furnace

# **Bosch BGH96 Model**

RevC | Compatible with Bosch R454B Products











# **Table of Contents**

1	Key to Symbols and Safety Instructions	4
1.1	Key to Symbols	4
1.2	Safety	4
2	Dimensions	7
3	Introduction	8
4	Codes and Standards	9
11	Safety	9
	General Installation	9
	Combustion and Ventilation Air	10
	Duct Systems	10
	Acoustical Lining and Fibrous Glass Duct	10
	Gas Piping and Gas Pipe Pressure Testing	10
	Electrical Connections	10
4.8	Electrical Power Supply	10
	Venting	10
5	Electrostatic Discharge (ESD) Precautions Procedure	10
6	Location	11
_		
7	Installation	13
	Upflow Installation	13
	Horizontal Installation	14
	1 Furnace Suspension	14
	2 Horizontal Applications	15
7.3	Condensate Line and Over Flow Pressure Switch	17
	7.3.1 Standard Right-Hand or Left-Hand Side Drain Hose Connections	17
	7.3.2 For Upflow Installation	18
	7.3.3 For Horizontal Installations	20
7.4	Filter Arrangement	24
	Air Ducts	25
7.6	Blower Fan Speed Adjustment	28
_		
8	Combustion Air and Vent System	30
	Combustion Air and Vent Safety	30
	Combustion Air/Vent Pipe Sizing	30
	Combustion Air And Vent Piping Assembly	32
	Combustion Air / Venting	33
	Vent System .1 Concentric Vent Termination Kit	34 35
	.2 Flush-Mount Vent Termination Kit	38
	Combustion & Ventilation Air Requirements	41
0.0	8.6.1 Combustion Air Supply	41
	8.6.2 Outdoor Combustion Air	41
	8.6.3 Ambient Combustion Air	41
	8.6.4 Ventilated Combustion Air	43
8.7	Vent and Supply (Outside) Air Safety Check Procedure	44
9	Gas Supply and Piping	45
	General	<b>45</b>
	High Altitude Derate	45
	Propane Gas (LP) Conversion	40
	Gas Piping Connections	47
	Gas Piping Checks	48
5	ı <u>u</u>	.0

17	Wiring Diagram	74
16	Before Leaving Installation	72
	Repair and Replacement Parts	72
	Condensate Drain	72
	Inspecting the Heat Exchanger (Qualified Service Technicians Only)	72
	Burners	72
	Ignitor (Qualified Service Technicians Only)	72
	Flame Sensor (Qualified Service Technicians Only)	71
	Induced Draft Blower And Indoor Blower Motors	71 71
	Annual Inspection Filters	71 71
		71 71
14.3 <b>15</b>	Troubleshooting Chart  Service and Maintenance Procedures	68 <b>71</b>
14.2	Resetting From Lockout	68
	Electrostatic Discharge (ESD) Precautions	68
14	Troubleshooting	68
	Flame Sensor	67
	Pressure Switches	67
	Reverse Flow Limits Overflow Protection Pressure Switch (Overflow Switch)	67 67
	Rollout Limits	67 67
	Primary Limit	67
	Integrated Control Module	67
	General	67
13	Safety Circuit Description	67
12	Operational Checks	67
	Temperature Rise Adjustment	66
	Gas Input Rate Measurement (Natural Gas Only)	65
	Sequence of Operation Gas Manifold Pressure Measurement and Adjustment	63 64
	Furnace Start-Up	62
	Start-Up Procedures	62
	General	62
	Start-Up, Adjustment, and Safety Check	62
	Non-Communicating Setup	60
	10.9.4 Thermostat Wiring - Dual Fuel application,	
	Communicating Setup	57
	10.9.3 Thermostat Wiring - Dual Fuel Application,	30
	10.9.1 Thermostat Settings 10.9.2 Thermostat Wiring - Furnace Only Application (Fossil Fuel)	55 56
10.9	Thermostat Settings and Wiring	55
	Refrigerant Leakage Sensors	54
	Grounding	50
	Accessories (Field Supplied)	50
10.5	24V Wiring	50
	BX Cable Installation in Furnace J-box	50
	Power Cord Installation in Furnace J-box	50
	115V Wiring Electrical Connection to J-box	50
	Electrical Connections	<b>49</b>
10	Floatrical Compositions	40



# 1 Key to Symbols and Safety Instructions

# 1.1 Key to Symbols

# Warnings

In warnings, signal words at the beginning of a warning are used to indicate the type and seriousness of the ensuing risk if measures for minimizing danger are not taken.

The following keywords are defined and can be used in this document:



#### **DANGER**

**DANGER** indicates a hazardous situation which, if not avoided, will result in death or serious injury.



#### **WARNING**

**WARNING** indicates a hazardous situation which, if not avoided, could result in death or serious injury.



#### **CAUTION**

**CAUTION** indicates a hazardous situation which, if not avoided, could result in minor to moderate injury.

#### **NOTICE**

**NOTICE** is used to address practices not related to personal injury.

#### Important information



The info symbol indicates important information where there is no risk to people or property.

# 1.2 Safety

Please read all instruction in the manual and retain all manuals for future reference.



INSTALLER: Use the information in this booklet to install the appliance and affix this booklet adjacent to the appliance after installation.

USER: Keep this booklet of information for future reference. Refer to the User's Information Manual for more information.

SERVICER: Use the information in this booklet to service the appliance and affix the booklet adjacent to the appliance after servicing.



#### WARNING

#### Fire or explosion hazard!

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WHAT TO DO IF YOU SMELL GAS:

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Leave the building immediately.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

Installation and service must be performed by a qualified installer, service agency, or the gas supplier.



# WARNING

# Fire or explosion hazard!

Do not use this furnace if any part has been under water. A flood-damaged furnace is extremely dangerous. Attempts to use the furnace can result in fire or explosion. A qualified service agency should be contacted to inspect the furnace and to replace all gas controls, control system parts, and electrical parts that have been wet, or the furnace if deemed necessary.



# WARNING

#### Fire or explosion hazard!

The furnace is designed and approved for use with Natural Gas and (LP) Propane Gas ONLY.

DO NOT BURN ANY LIQUID FUEL OR SOLID FUEL IN THIS FURNACE.

Burning any unapproved fuel will result in damage to the furnace's heat exchanger, which could result in Fire, Personal Injury, and/or Property Damage.



### WARNING

# Personal injury!

# FOLLOW ALL SAFETY CODES.

Wear safety glasses, protective clothing, and work gloves. Have a fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions included in literature and attached to the unit. Consult local building codes as well as the current editions of the National Fuel Gas Code (NFGC) NFPA 54/ANSI Z223.1 and the National Electrical Code (NEC) NFPA 70.





#### WARNING

# Fire, explosion, electrical shock, and carbon monoxide poisoning hazard!

Failure to follow this warning could result in dangerous operation, serious injury, death, or property damage. Improper installation, adjustment, alteration, maintenance, or use could cause carbon monoxide poisoning, explosion, fire, electrical shock, or other conditions which may cause personal injury or property damage. Consult a qualified service agency, local gas supplier, or your distributor for information or assistance.



#### **CAUTION**

#### Cut hazard

Failure to follow this caution may result in personal injury. Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing furnaces



#### **CAUTION**

#### Installation requirements!

Use only with type of gas approved for this furnace. Refer to the furnace rating plate.

Install this furnace only in a location and position as specified in Section 6 "Location" of these instructions.

Provide adequate combustion and ventilation air to the furnace space as specified in Section 8.4 "Combustion Air / Venting".

Combustion products must be discharged outdoors. Connect this furnace to an approved vent system only, as specified in Section 8.5 "Vent System" of this manual.

When a furnace is installed so that supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by duct(s) sealed to the furnace cabinet and terminating outside the space containing the furnace. See Section 7.5 "Air Ducts".

A gas-fired furnace for installation in a residential garage must be installed as specified in the warning box in Section 6 "Location".

The furnace may be used for construction heat provided that the furnace installation and operation complies with the first CAUTION in Section 6 "Location" of these instructions.



# WARNING

#### Fire hazard!

Failure to follow this caution may result in personal injury. Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing furnaces



# WARNING

#### Fire, explosion!

Check entire gas assembly for leaks after lighting this appliance.

Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections, as specified in Section 9 "Gas Supply and Piping" section.



#### WARNING

# Fire hazard!

The furnaces must be kept free and clear of insulating materials. Inspect surrounding area to ensure insulation material is at a safe distance when installing furnaces or adding insulation materials. Insulation materials may be combustible.

See Section 3, Fig. 3 for required clearances to combustible construction.

Maintain a 1 in. clearance from combustible materials to supply air ductwork for a distance of 36 in. horizontally from the furnace. See NFPA 90B or local code for further requirements.

These furnaces SHALL NOT be installed directly on carpeting, tile, or any other combustible material other than wood flooring. This furnace SHALL NOT be installed in the downflow orientation.



#### **WARNING**

#### Improper or dangerous operation!

Improper installation or misapplication of furnace may require excessive servicing or cause premature component failure. Application of this furnace should be indoors with special attention given to vent sizing and material, gas input rate, air temperature rise, unit leveling, and unit sizing.

#### NOTICE

#### Property damage!

The condensate from this unit is acidic, ensure that all local and national codes are adhered to when draining condensate. If proper procedures are not followed, this may lead to property damage.



#### **CAUTION**

# Fire, explosion, electrical shock, and carbon monoxide poisoning hazard!

Before heating season begins, examine the furnace to ensure that:

- All flue gas carrying areas external to the furnace (i.e. chimney, vent connector) are clear and free of obstructions.
- The vent connector is in place, slopes upward and is physically sound without holes or excessive corrosion.
- The return-air duct connection(s) is physically sound, is sealed to the furnace cabinet, and terminates outside the space containing the furnace.
- The physical support of the furnace is sound without sagging, cracks, gaps, etc around the base so as to provide a seal between the support and the base.
- 5. There are no obvious signs of deterioration of the furnace.
- The burner flames are positioned correctly by comparing with pictorial sketches of the main burner flame (see Section 12, figure 63)





# WARNING

# Fire or explosion hazard!

See instructions for lighting/shutdown operation (as shown at the bottom of this page, as well as on a sticker directly on the inside of the furnace panel). Should the gas supply fail to shut off or if overheating occurs, shut off the gas valve to the furnace before shutting off the electrical supply.



#### WARNING

#### Carbon monoxide poisoning hazard!

Furnace operation requires air for combustion and ventilation. Do not block or obstruct air openings on furnace or spacing around furnace required for supplying sufficient combustion air and ventilation.



#### WARNING

#### Personal injury!

This product can expose you to chemicals including Lead and Lead components, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to <a href="https://www.P65Warnings.ca.gov">www.P65Warnings.ca.gov</a>.

#### Instructions for lighting/shutdown operation:

# FOR YOUR SAFETY READ BEFORE OPERATING





If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

- A. This appliance does not have a pilot, it is equipped with an ignition device which automatically lights the burner. **Do** <u>not</u> try to light the burner by hand.
- B. BEFORE OPERATING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle to the floor.


#### FOR YOUR SAFETY "WHAT TO DO IF YOU SMELL GAS"

- Do not try to light any appliance
- · Do not touch any electrical switch; do not use any phone in your building
- · Immediately call your gas supplier from a

- neighbor's phone. Follow the gas supplier's instructions
- · If you cannot reach your gas supplier, call the fire department.
- C. Use only your hand to push the gas control switch. Never use tools. If the switch will not move by hand, don't try to repair it; call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water

# OPERATING INSTRUCTIONS

- 1. STOP! Read the safety information above on this label.
- Set the thermostat to lowest setting.
- Turn off all electric power to the appliance.
- 4. This appliance is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.



**SWITCH SHOWN IN** THE "OFF" POSITION

- Remove access panels.
- Push gas control switch to "OFF"
- Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas, **STOP!** Follow "B" in the safety information above on this label. If you don't smell gas, go to the next step.
- Push gas control switch to "ON".
- Replace access panels.
- 10. Turn on all electric power to the appliance.11. Set thermostat to desired setting12. If the appliance will not operate, follow the
- instructions "To Turn Off Gas To Appliance" and call your service technician or gas supplier.

# TO TURN OFF GAS TO APPLIANCE

- Set the thermostat to lowest setting.
- 2. Turn off all electric power to the appliance if service is to be performed.
- 3. Remove access panels.
- 4. Push gas control switch to "OFF".
- 5. Replace access panels.

202082290022



# 2 Dimensions




Figure 1 Dimensions

Furnace Model	"A" Cabinet Width In. (mm)	"D" Supply- Air Width In. (mm)	"E" Return- Air Width In. (mm)	Shipping Weight lbs (kg)
BGH96M060B3C	17.5 (445)	16 (406)	15-27/32 (402)	147.5 (66.9)
BGH96M080B3C	17.5 (445)	16 (406)	15-27/32 (402)	152 (68.9)
BGH96M080C4C	21 (533)	19.5 (495)	19-13/32 (493)	165 (74.8)
BGH96M100C5C	21 (533)	19.5 (495)	19-13/32 (493)	170.5 (77.3)
BGH96M100D5C	24.5 (622)	23 (584)	22-27/32 (580)	181.5 (82.3)
BGH96M120D5C	24.5 (622)	23 (584)	22-27/32 (580)	187 (84.8)

Table 1 Dimensions & weight



#### 3 Introduction

This 3-way Multipoise Category IV Fan-assisted furnace is AHRI and ETL design-certified. A Category IV Fan-assisted furnace is an appliance equipped with an integral mechanical means to either draw or force products of combustion through the combustion chamber and/or heat exchangers. This furnace is factory-shipped for use with natural gas.

This furnace is not approved for installation in mobile homes, recreational vehicles, or outdoors. This furnace is designed for minimum continuous return-air temperature of 60°F (16°C) (DBT) or intermittent operation down to 55°F (13°C) (DBT) such as when used with a night setback thermostat. Return-air temperature must not exceed 85°F (29°C) (DBT). Failure to follow these return-air temperature limits may affect reliability of heat exchangers, motors, and controls. (See Section 4.1, Fig. 5).

For accessory installation details, refer to the applicable instruction literature. A Natural Gas to LP conversion kit, supplied by the manufacturer with every furnace unit, shall be used to convert to propane gas (LP).

This furnace is for indoor installation in a building constructed on-site.

This furnace may be installed on combustible flooring in alcove or closet at minimum clearance as indicated by Figure 3.

This furnace requires a special venting system. Refer to Section 8, "Vent System" of this manual for installation instructions related to venting. In the US this furnace is for use with schedule-40 PVC, PVC-DWV, CPVC, or ABS-DWV pipe, and must not be vented in common with other gas-fired appliances. For installations in Canada, refer to Section 8.4, "Combustion Air/Venting" of this manual. Construction through which vent/air intake pipes may be installed is maximum 24 inches (610 mm), minimum 3/4 inches (19 mm) thickness (including roofing materials).



Remove all shipping brackets and materials before operating the furnace.



# WARNING

#### Fire, explosion, asphyxiation hazard!

Improper adjustment, alteration, service, maintenance, or installation can cause serious injury or death.

Read and follow instructions and precautions in User's Information Manual provided with this furnace. Installation and service must be performed by a qualified service agency or the gas supplier.



This product is not to be sold or installed in the State of California in the South Coast Air Quality Management District or San Joaquin Valley Air Basin territory.

# **CAUTION**

#### Fire, explosion, electrical shock, and carbon monoxide poisoning hazard!

#### INSTALLATION

- This furnace must be installed in accordance with the manufacturer's instructions and local codes. In the absence of local codes, follow the National Fuel Gas Code ANSI Z223.1/ NFPA54.
- This furnace must be installed so there are provisions for combustion and ventilation air. See manufacturer's installation information provided with this appliance.

#### **OPERATION**

This furnace is equipped with manual reset limit switch(es) in burner compartment to protect against overheat conditions that can result from inadequate combustion air supply or blocked vent conditions.

- 1. Do not bypass limit switches.
- If a limit opens, call a quallified service technician to correct the condition and reset the limit switch.

This furnace is approved for UPFLOW and HORIZONTAL installations.



#### **WARNING**

#### Fire hazard!

Do not install the furnace on its front or back. See Figure 2.




Figure 2






Figure 3 Minimum clearance from combustible construction

- ★ Supply and return locations when furnace is installed in horizontal position. When in the horizontal orientation, there must be 7" clearance in order to install the externally mounted drain trap.
- \*\* If installed in an alcove or closet 24" is required for service and maintenance.

# Horizontal installation in attic or crawl space

When installed in an attic or crawl space, the furnace must be installed with back of the furnace cabinet in line and along building joists, studs or frame. Horizontal applications require a solid, supportive structure for installation (refer to Section 7.2 "Horizontal Installation").

For upflow and horizontal applications, the furnace must be pitched a minimum of 1/2" (12.7 mm) to a maximum of 3/4" (19 mm) forward for proper drainage. See Section 7, "Installation" of this manual for more information.




Figure 4

# 4 Codes and Standards

Follow all national and local codes and standards in addition to these instructions. The installation must comply with regulations of the serving gas supplier, local building, heating, plumbing, and other codes. In absence of local codes, the installation must comply with the national codes listed below and all authorities having jurisdiction. Follow all codes and standards for the following:

#### 4.1 Safety

- US: National Fuel Gas Code (NFGC) NFPA 54-Latest/ANSI Z223.1latest edition and the Installation Standards, Warm Air Heating and Air Conditioning Systems ANSI/NFPA 90B
- CANADA: National Standard of Canada Natural Gas and Propane Installation Codes (CAN/CSA-B149.1-05)




Figure 5 Return air temperature

# 4.2 General Installation

- US: Current edition of the NFGC and the NFPA 90B. For copies, contact
  the National Fire Protection Association Inc., 1 Batterymarch Park,
  Quincy, MA 02169; (www.NFPA.org) or for only the NFGC, contact the
  American Gas Association, 400 North Capital Street, NW, Suite 450,
  Washington, DC 20001 (www.AGA.org)
- CANADA: NSCNGPIC.For a copy, contact Standard Sales, CSA International, 178 Rexdale Boulevard, Etobicoke (Toronto), Ontario, M9W 1R3 Canada



# 4.3 Combustion and Ventilation Air

- US: Section 9.3 of the NFGC, NFPA 54/ANSI Z223.1-latest edition Air for Combustion and Ventilation
- CANADA:Part 8 of CAN/CSA-B149.1-05, Venting Systems and Air Supply for Appliances.

### 4.4 Duct Systems

US and CANADA: Air Conditioning Contractors Association (ACCA)
 Manual D, Sheet Metal and Air Conditioning Contractors National
 Association (SMACNA), or American Society of Heating, Refrigeration,
 and Air Conditioning Engineers (ASHRAE) 2001 Fundamentals Handbook
 Chapter 34.

# 4.5 Acoustical Lining and Fibrous Glass Duct

 US and CANADA: Current edition of SMACNA and NFPA 90B as tested by UL Standard 181 for Class I Rigid Air Ducts

#### 4.6 Gas Piping and Gas Pipe Pressure Testing

- US: NFPA 54/ANSI Z223.1-latest edition Chapters 5,6,7, and 8 and National Plumbing Codes
- CANADA: CAN/CSA-B149.1-05 Parts 4,5 and 6 and Appendices A,B,E,and H.

# 4.7 Electrical Connections

- US: National Electrical Code (NEC) ANSI/NFPA 70-latest edition
- CANADA: Canadian Electrical Codes CSA C22.1.

# 4.8 Electrical Power Supply

· Voltage: ANSI C84.1- latest edition (104-127 volt)

#### 4.9 Venting

- US: NFGC NFPA 54/ANSI Z223.1-latest edition; Chapters 12 and 13
- CANADA: CAN/CSA-B149.1-05 Part 8 and Appendix C.

# 5 Electrostatic Discharge (ESD) Precautions Procedure



# WARNING

# Improper or dangerous operation, product damage!

Improper installation or service of furnace may cause premature furnace component failure.

Electrostatic discharge can affect electronic components. Follow the electrostatic discharge precautions procedure listed below during furnace installation and servicing to protect the furnace electronic control. Precautions will prevent electrostatic discharges from personnel and hand tools which are held during the procedure. These precautions will help to avoid exposing the control board to electrostatic discharge by putting the furnace, the control board, and the person at the same electrostatic potential.

- Disconnect all power to the furnace. Multiple disconnects maybe required. DO NOT TOUCH THE CONTROL OR ANY WIRE CONNECTED TO THE CONTROL PRIOR TO DISCHARGING YOUR BODY'S ELECTROSTATIC CHARGE TO GROUND.
- To discharge your body's electrostatic charge to ground, firmly touch the clean, unpainted, metal surface of the furnace chassis which is close to the control board. Tools held in a person's hand during grounding will be satisfactorily discharged.
- After touching the chassis, you may proceed to service the control board or connecting wires as long as you do nothing to recharge your body with static electricity (for example; DO NOT move or shuffle your feet, do not touch ungrounded objects, etc.).
- If you touch ungrounded objects (and recharge your body with static electricity), firmly touch a clean, unpainted metal surface of the furnace again before touching control board or wires.

Use this procedure for installed and uninstalled (ungrounded) furnaces. In the case of control board replacement, before removing the replacement control board from its packaging, discharge your body's electrostatic charge to ground to protect the control from damage. If the control is to be installed in a furnace, follow steps 1 through 4 before bringing the control board or yourself in contact with the furnace. Put all used and new control boards into containers before touching ungrounded objects.

An ESD service kit (field supplied) may also be used to prevent ESD damage.



#### 6 Location

This multipoise furnace is shipped in packaged configuration. Some assembly and modifications are required when used in any of the three applications . This furnace must:

- Be installed so the electrical components are protected from water.
- Not be installed directly on any combustible material other than wood flooring. Refer to Section 3 Fig 3. for required clearances.
- Horizontal installation in attics and crawl spaces have additional requirements. Refer to Section 7.
- Be located close to the chimney or vent and attached to an air distribution system. Refer to Section 7.5 "Air Ducts".
- Be provided ample space for servicing and cleaning. Always comply with minimum fire protection clearances shown on the furnace clearance to combustible label. Refer to Section 3, Fig 3.

The following types of furnace installations may require OUTDOOR AIR for combustion due to chemical exposures:

- · Commercial buildings
- · Buildings with indoor pools
- · Laundry rooms
- · Hobby or craft rooms, and
- · Chemical storage areas



#### WARNING

### Carbon monoxide poisoning hazard!

Failure to follow this warning could result in personal injury or death, and unit component damage.

Corrosive or contaminated air may cause failure of parts containing flue gas, which could leak into the living space. Air for combustion must not be contaminated by halogen compounds, which include fluoride, chloride, bromide, and iodide. These elements can corrode heat exchangers and shorten furnace life. Air contaminants are found in aerosol sprays, detergents, bleaches, cleaning solvents, salts, air fresheners, and other household products. Do not install furnace in a corrosive or contaminated atmosphere. Make sure all combustion and circulating air requirements are met, in addition to all local codes and ordinances.

If air is exposed to the following substances, it should not be used for combustion air, and outdoor air may be required for combustion:

- · Permanent wave solutions
- Chlorinated waxes and cleaners
- · Chlorine based swimming pool chemicals
- · Water softening chemicals
- De-icing salts or chemicals
- · Carbon tetrachloride
- · Halogen type refrigerants
- · Cleaning solvents (such as perchloroethylene)
- · Printing inks, paint removers, varnishes, etc.
- · Hydrochloric acid
- · Cements and glues
- · Antistatic fabric softeners for clothes dryers
- Masonry acid washing materials

All fuel-burning equipment must be supplied with air for fuel combustion. Sufficient air must be provided to avoid negative pressure in the equipment room or space. A positive seal must be made between the furnace cabinet and the return-air duct to prevent pulling air from the burner area and from draft safeguard opening. Also see Section 7.5 "Air Ducts".




Figure 6 Installation in a garage





# WARNING

# Fire, injury or death hazard!

When the furnace is installed in a residential garage, the burners and ignition sources must be located at least 18 inches above the floor. The furnace must be located or protected to avoid damage by vehicles. When the furnace is installed in a public garage, airplane hangar, or other building having a hazardous atmosphere, the furnace must be installed in accordance with the NFGC. (See Fig. 6).



# **CAUTION**

#### Injury and/or property damage hazard!

Improper use or installation of this furnace may cause premature furnace component failure. This gas furnace may be used for heating buildings under construction provided that:

- The furnace is permanently installed with all electrical wiring, piping, venting and ducting installed according to these installation instructions. A return air duct is provided, sealed to the furnace cabinet, and terminated outside the space containing the furnace. This prevents a negative pressure condition as created by the circulating air blower, causing a flame rollout and/or drawing combustion products into the structure.
- The furnace is controlled by a thermostat. It may not be "hot wired" to
  provide heat continuously to the structure without thermostatic control.
- Clean outside air is provided for combustion. This is to minimize the
  corrosive effects of adhesives, sealers and other construction materials. It
  also prevents the entrainment of drywall dust into combustion air, which
  can cause fouling and plugging of furnace components.
- The temperature of the return air to the furnace is maintained between 60°F (16°C) and 85°F (29°C), with no evening setback or shutdown.
- The use of the furnace while the structure is under construction is deemed to be intermittent operation per our installation instructions.
- The air temperature rise is within the rated rise range on the furnace rating plate, and the gas input rate has been set to the nameplate value.
- The filters used to clean the circulating air during the construction process must be either changed or thoroughly cleaned prior to occupancy.
- The furnace, ductwork and filters are cleaned as necessary to remove drywall dust and construction debris from all HVAC system components after construction is completed.
- Verify proper furnace operating conditions including ignition, gas input rate, air temperature rise, and venting according to these installation instructions.



# 7 Installation

This furnace can be installed in upflow or horizontal orientations.

# 7.1 Upflow Installation

# **Bottom return air inlet**

These furnaces are shipped with the bottom closure panel installed in bottom return-air opening. Remove and discard this panel when bottom return air is used. To remove bottom closure panel, perform the following:

- Tilt or raise furnace and remove the screw holding bottom filler panel. (See Fig. 7.)
- 2. Remove bottom closure panel.




Figure 7 Removing bottom closure panel

#### Side return air inlet

These furnaces are shipped with bottom closure panel installed in bottom return-air opening. This panel MUST be in place if only side return air is used.



Depending on the installation requirements, side return-air openings can be used in UPFLOW and most HORIZONTAL configurations.



These furnaces come standard with knockout holes to aid in right/left return configurations. To do this, knockout the holes and cut the sheet metal and insulation accordingly.




Figure 8 Upflow application-setting equipment



# 7.2 Horizontal Installation



# WARNING

# Fire, explosion, and carbon monoxide poisoning hazard!

Failure to follow this warning could result in personal injury, death, and/or property damage. Do not install the furnace on its back or hang furnace with control compartment facing downward. Safety control operation will be adversely affected. Never connect return-air ducts to the back of the furnace.

The furnace can be installed horizontally in an attic or crawl space on bottom or either the left-hand (LH) or right-hand (RH) side (See Figure 9). The furnace can be hung from floor joists, rafters or trusses or installed on a non-combustible platform, blocks, bricks or pad.

# 7.2.1 Furnace Suspension

If suspending the furnace from rafters or joists, use 3/8" threaded rod and 2"x2"x1/8" angle iron as shown in Figure 10. The length of rod will depend on the application and the clearances necessary. (See Fig. 10 and 11)




Figure 9 Horizontal application-setting equipment



#### 7.2.2 Horizontal Applications

Horizontal applications, in particular, may dictate many of the installation's specifics such as airflow direction, ductwork connections, flue and combustion air pipe connections, etc. The basic application of this furnace as a horizontal furnace differs only slightly from an upright installation. When installing a furnace horizontally, additional consideration must be given to the following:

#### **Drain Trap and Lines**

In horizontal applications the condensate drain trap is secured to the furnace side panel, suspending it below the furnace.



A minimum clearance of 7 inches below the furnace must be provided for the drain trap.

Additionally, the appropriate downward piping slope must be maintained from the drain trap to the drain location. Refer to Section "Condensate Drain Line & Drain Trap".

#### NOTICE

#### Product damage!

If the drain trap and drain line will be exposed to temperatures near or below freezing, adequate measures must be taken to prevent condensate from freezing. In this scenario, it is recommended to add foam insulation around the drain line, and heat tracing may also be necessary based on the application.

### Leveling

Leveling ensures proper condensate drainage from the heat exchanger and induced draft blower. For proper flue pipe drainage, the furnace must be level lengthwise from end to end. The furnace should also have a slight tilt with the access doors downhill ((minimum 1/2 (12.7 mm) to maximum of 3/4 (19 mm)) from the back panel. The slight tilt allows the heat exchanger condensate, generated in the recuperator coil, to flow forward to the recuperator coil front cover. Refer to Figure 9.

#### **Alternate Electrical And Gas Line Connections**

This furnace has provisions allowing for electrical and gas line connections through either side panel. In horizontal applications the connections can be made either through the "top" or "bottom" of the furnace.

# **Drain Pan**

A drain pan must be provided if the furnace is installed above a conditioned area. The drain pan must cover the entire area under the furnace (and air conditioning coil if applicable).

### **Furnace Suspension**

If the furnace is installed in a crawl space it must be suspended from the floor joist or supported by a concrete pad. Never install the furnace on the ground or allow it to be exposed to water. See Furnace Suspension for further details (See Fig. 10).




Figure 10 Horizontal installation




Figure 11 Horizontal installation



# 7.3 Condensate Line and Over Flow Pressure Switch

# NOTICE

#### Product damage!

For horizontal left hand installation (air discharge to the left), condensate overflow pressure switch hoses need to be rerouted (see Figure 19).

To achieve higher energy efficiency than non-condensing furnaces, condensing furnaces will generate a significant amount of condensate water from combustion to recover latent heat in the flue. Condensate generated from the flue must be collected and discharged to the drain line. For some venting directions and furnace installations, rerouting of the condensate and/or overflow pressure switch hoses may be required. Follow the instructions below and Figures 13-17 for each installation.

Follow the information listed below when installing the drain system. Refer to the following sections for specific details concerning furnace drain trap installation and drain hose hook ups.

- The drain trap supplied with the furnace must be used.
- The drain line between furnace and drain location must be constructed of 3/4" PVC hose or CPVC hose pipe.
- Ensure that the condensate hose connections between the pressure switches/inducer drain port and the condensate trap are sloped downward toward the drain to allow for proper drainage.
- The drain line between furnace and drain location must maintain a 1/4" per foot downward slope toward the drain.
- Do not trap the drain line in any other location than at the drain trap supplied with the furnace.
- Do not route the drain line outside where it may freeze.
- It is recommended to install a PVC tee (field supplied) coming directly out
  of the drain trap.

- If the drain line is routed through an area which may see temperatures
  near or below freezing, precautions must be taken to prevent
  condensate from freezing within the drain line. In this scenario, it is
  recommended to add foam insulation around the drain line, and heat
  tracing may also be necessary based on the application.
- If an air conditioning coil is installed with the furnace, a common drain
  may be used. An open tee must be installed in the drain line, near the
  cooling coil, to relieve positive air pressure from the coil's plenum. This is
  necessary to prohibit any interference with the function of the furnace's
  drain trap.

#### **NOTICE**

#### Product damage!

The condensate from this unit is acidic, adhere to all local and national codes when draining condensate. If proper procedures are not followed, this may lead to property damage.

#### NOTICE

#### Product damage!

Condensate trap at furnace must be PRIMED or proper draining may not occur. The condensate trap can ONLY be primed by pouring water into the inducer drain side of condensate trap.

#### 7.3.1 Standard Right-Hand or Left-Hand Side Drain Hose Connections




Figure 12 Included accessories for condensate drain trap installation

<sup>\*</sup> Only used when exhaust pipe is vented out of the side of the furnace's cabinet (regardless of installation orientation).

# 7.3.2 For Upflow Installation

# Top venting (see Fig. 15)

- Connect vent pipe and air intake pipe (if applicable) to the couplers on the furnace top panel.
- Use filed supplied straight 2" diameter pipe. If 3" pipes are used, use a field supplied transition.
- 3. Depending on which side the condensate trap is mounted, remove 2 caps on the side where trap is mounted. Mount trap with manufacturer provided screws.
- 4. Remove cap from the inducer drain port (see Fig. 13).




Figure 13

- 5. Connect  $\Phi$ 16 mm hose between condensate collector box and drain trap and connect  $\Phi$ 14 mm hose between inducer drain port and drain trap. (see Fig. 15).
- 6. Cut the excess hoses as needed.




Figure 14

Model	X1/mm	X2/mm
BGH96M100D5C BGH96M120D5C	60	84
BGH96M080C4C BGH96M100C5C	135	149
BGH96M060B3C BGH96M080B3C	240	219

Table 2

7. Secure and tighten all hoses using manufacturer provided hose clamps.




Figure 15 Upflow installation, top venting



# Right side venting (see Fig. 16)

- Remove plug (14mm) from right side panel of furnace and cut the insulation to the size.
- Remove 3 screws securing air intake coupler on top panel and remove coupler.
- Mount coupler to the leftt side using the same screws saved from removing top panel coupler.
- 4. Cover the top panel opening using the plug removed from left side panel.
- Remove rubber elbow connected to the inducer. Use field provided 2" plastic pipe and nipple to connect to the inducer.
- Connect rubber elbow to the 2" pipe out side the unit. Elbow should be connected as close to the side panel as possible.
- 7. Connect 2" pipe to the rubber elbow. If 3" pipes are used, use a field provided transition.
- 8. Use provided or field supplied (if applicable) mounting bracket to mount condensate trap on the proper location of right side panel.
- Screws for mounting bracket should not interfere any components inside the furnace.
- Connect 16mm hose between collector box and trap and connect 14mm hose between rubber elbow and trap.
- 11. Cut the excess hoses if necessary.
- 12. Relocate junction box to the other side of cabinet if necessary.
- 13. Secure and tight all hoses.




Figure 16 Upflow installation, right side venting



#### 7.3.3 For Horizontal Installations

# For installations with right air discharge and venting outlet through furnace top panel (see Figure 17).

- Remove cap from left side panel of furnace and cut the insulation accordingly.
- Remove 3 screws securing air inlet coupler on top panel and remove coupler.
- 3. Mount air inlet coupler to the left side of the furnace cabinet using the same screws saved from last step. Connect air inlet pipe to air inlet coupler.
- 4. Seal the top panel air intake hole using the caps removed from side panel.
- 5. Use field supplied elbow and metal hose clamps to make flue vertical. Elbows should be as close to the furnace as possible. Connect the vent outlet pipe. Use filed supplied straight 2" diameter pipes. If 3" diameter pipes are used, use a field supplied transition.
- Use provided or field supplied (if applicable) mounting bracket to mount drain trap to the proper location on right side panel.
- Screws for mounting bracket should not interfere with any components inside the furnace.
- 8. Cut and remove 1/4" from the end of the inducer drain port. Reference Figure 14.
- Connect (using hose clamps) 16 mm hose between condensate collector box and drain trap.
- Connect (using hose clamps) 14 mm hose between the drain port and drain tran.
- 11. Cut the excess hose as needed.
- 12. Secure and tighten all hoses




Figure 17 Horizontal right-hand side installation



For installations with left air discharge and venting outlet through furnace top panel (see Figure 20).

#### NOTICE

# Product damage, property damage!

In this installation, hoses connecting between ports of overflow protection pressure switch (overflow switch) and pressure tabs on the condensate collector box MUST be switched. The overflow switch has two ports, which is different from two other regular pressure switches that have only one port. Make sure that black port (positive) is connected to the lower position tap on condensate collector box and gray port (negative) to higher tap of condensate box. Connecting incorrectly will result in failure to protect condensate overflow. See Fig. 18 and 19.

#### **NOTICE**

#### Product damage, property damage!

Two pressure switches (one port type switches) should be relocated to other side of furnace side panel to ensure pressure switches are above water tap of condensate collector box.




Figure 18

- Remove cap from left side panel of furnace and cut the insulation accordingly.
- Remove 3 screws securing air inlet coupler on top panel and remove coupler.
- Mount coupler to the right side using the same screws saved from last step.
   Connect air inlet pipe to air inlet coupler.
- 4. Seal the top panel air intake hole using the caps removed from side panel.
- Use field supplied elbow and metal hose clamp to make flue vertical. Elbows should be as close to the furnace as possible. Connect the vent outlet pipe.
- Use provided or field supplied (if applicable) mounting bracket to mount condensate trap on the proper location of the left side panel.
- Screws for mounting bracket should not interfere with any components inside the furnace.
- 8. Connect 16 mm hose between condensate collector box and drain trap. Cut the excess hose to correct length prior to connection.
- Connect 14 mm hose between the side inducer drain port (remove black rubber plug to connect hose) and drain trap. Refer to Figure 20.
- 10. Plug both holes on inducer elbow using provided plugs.
- 11. Cut the excess hoses as needed.
- 12. Secure and tighten all hoses.
- 13. Relocate junction box to the other side of cabinet if necessary.
- 14. Relocate the High/Low Fire Pressure Switches (2) to the opposite side of the cabinet (as shown in Figure 19 and 20). Screws for mounting these switches should not interfere with any components inside the furnace.




Figure 19 Pressure switch position




Figure 20 Horizontal left side installation, vent through top panel



For installations with left air discharge and venting outlet through furnace side panel (see Figures 19 and 21).

#### **NOTICE**

#### Product damage, property damage!

In this installation, hoses connecting between ports of overflow protection pressure switch (overflow switch) and pressure tabs on the condensate collector box MUST be switched. The overflow switch has two ports, which is different from two other regular pressure switches that have only one port. Make sure that black port (positive) is connected to the lower position tap on condensate collector box and gray port (negative) to higher tap of condensate box. Connecting incorrectly will result in failure to protect condensate overflow. See Fig. 18 and 19.

#### NOTICE

#### Product damage, property damage!

Two pressure switches (one port type switches) should be relocated to other side of furnace side panel to ensure pressure switches are above water tap of condensate collector box.

- Remove plug (14mm) from furnace's right side panel and cut the insulation to the size.
- Remove 3 screws securing air intake coupler on top panel and remove coupler.
- Mount coupler to the right side using the same screws saved from removing top panel coupler.
- 4. Cover the top panel opening using the plug removed from side panel
- Remove 16mm knockout on right panel and cut insulation. Install rubber grommet provided in the kit bag to 16mm opening.

- Remove rubber elbow connected to the inducer. Use field provided 2" plastic pipe and nipple to connect to the inducer.
- Connect rubber elbow to the 2" pipe. Elbow should be connected as close to the side panel as possible.
- 8. Secure and tight all hoses.
- 9. Connect 2" pipe to the rubber elbow. If 3" pipes are used, use a field provided transition.
- Use provided or field supplied (if applicable) mounting bracket to mount condensate trap on the proper location of right side panel.
- Screws for mounting bracket should not interfere any components inside the furnace.
- 12. Connect 16mm hose between collector box and trap and connect 14mm hose between inducer draining tap and trap.
- 13. Cut the excess hoses if necessary.
- 14. Relocate junction box to the other side of cabinet if necessary




Figure 21 Horizontal left side installation, vent through side panel



# 7.4 Filter Arrangement



# **CAUTION**

#### Fire hazard!

Never install a filter on the supply air side. Filters should always be installed on return air side of system.



#### **WARNING**

#### Carbon monoxide poisoning hazard!

Never operate a furnace without a filter or with filter access door removed.

#### **Filter Installation**

All applications require the use of a field installed filter. All filters and mounting provision must be field supplied. Filters must be installed external to the furnace cabinet. DO NOT attempt to install filters inside the furnace.

#### Filter size

The Bosch 96% AFUE Gas Furnace BGH96 series does not include a filter from the manufacturer. The filter and filter rack must be field supplied and field installed. A high velocity filter is recommended, see recommended filter size and type in Table 3. One of the most common causes of furnace malfunctions is a blocked or dirty filter. The filter must be inspected monthly for dirt accumulation and replaced if necessary.

#### Filter type

Air velocity through disposable filters may not exceed 300 feet per minute (FPM). All velocities over this require the use of high velocity filters. If a normal speed disposable filter is used and air speed exceeds 300 feet per minute (FPM), two side returns or one side return and the bottom return may be needed. For airflow, refer to Tables 4 & 5.

# NOTICE

#### Product damage, property damage!

If disposable filters are used, air passage through filters should be increased to twice the size of original air opening by using a transition duct or using two filters in V shape (see Fig. 22) in normal duct size.




Figure 22

#### Side return

Locate the 4 knockout locations. These indicate the size of the cut-out to be made in the furnace side panel. Refer to Fig 23, "Side Return Knockout Markings".




Figure 23 Side return knockout markings



Dimensions of return air "cut out" must match those shown in Figure 1. DO NOT cut outside of the "knockout" markings.

Install the side filter rack (field supplied) following the instructions provided with that accessory. If a filter(s) is provided at another location in the return air system, the duct work may be directly attached to the furnace side panel.

#### **Bottom Return filters**

Filter(s) may be located in the duct system outside the furnace using an external duct filter box attached to the furnace plenum or at the end of the duct in a return filter grille(s). The use of straps and/or supports is required to support the weight of the external filter box.



Single side return above 1800 CFM is approved as long as the filter velocity does not exceed filter manufacturer's recommendation and a transition is used to allow for a 20x25 filter.

Furnace cabinet width	Filte	Filter type	
runace capinet within	Side return	Bottom return	Filter type
17-1/2 (445)	16X25 (406X635)	16X25 (406X635)	High Velocity (600 FPM)
21 (533)	16X25 (406X635)	20X25 (508X635)	High Velocity (600 FPM)
24.5 (622)	16X25(406X635)	24X25 (610X635)	High Velocity (600 FPM)

Table 3 Manufacturer recommended high velocity filter sizes - Inch(mm)



#### 7.5 Air Ducts

#### **General requirements**

The duct system should be designed and sized according to accepted national standards such as those published by: Air Conditioning Contractors Association (ACCA), Sheet Metal and Air Conditioning Contractors National Association (SMACNA) or American Society of Heating, Refrigerating and Air Conditioning Engineers (ASHRAE) or consult The Air Systems Design Guidelines reference tables available from your local distributor. The duct system should be sized to handle the required system design CFM at the design external static pressure. The furnace airflow rates are provided in Tables 4 & 5 "Air Delivery - CFM (Without Filter)".

When a furnace is installed so that the supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by duct(s) sealed to the furnace cabinet and terminating outside the space containing the furnace.

Secure ductwork with the proper fasteners for type of ductwork used. Seal supply and return-duct connections to furnace with code approved tape or duct sealer.



Flexible connections should be used between duct work and furnace to prevent transmission of vibration. Duct work passing through unconditioned space should be insulated and sealed to enhance system performance. When air conditioning is used, a vapor barrier is recommended.

Maintain a 1-inch clearance betweem combustible materials and the supply air ductwork for a distance of 36 inch horizontally from the furnace. See NFPA 90B or local code for further requirements.

#### **Ductwork acoustical treatment**



Metal duct systems that do not have a 90 degree elbow and 10 ft. of main duct to the first branch take-off may require internal acoustical lining. As an alternative, fibrous duct work may be used if constructed and installed in accordance with the latest edition of SMACNA construction standard on fibrous glass ducts. Both acoustical lining and fibrous duct work shall comply with NFPA 90B as tested by UL Standard 181 for Class 1 Rigid air ducts.

#### Supply air connections

For a furnace not equipped with a cased coil, the outlet duct shall be provided with a removable access panel. This opening shall be accessible when the furnace is installed and shall be of such a size that the heat exchanger can be visually checked for possible damage using light assistance or a probe that can be inserted for sampling the airstream. The cover attachment shall prevent leaks.

#### **Upflow and horizontal furnaces**

Connect supply-air duct to flanges on furnace supply-air outlet. Bend flange upward to  $90^\circ$  with wide duct pliers. The supply-air duct must be connected to ONLY the furnace supply-outlet-air duct flanges or cased coil cabinet (when used).

#### **NOTICE**

#### Product damage!

DO NOT cut main furnace cabinet side to attach supply air duct, humidifier, or other accessories. All accessories MUST be connected to duct external to main furnace cabinet.



For horizontal applications, the top-most flange may be bent past 90 degrees to allow the evaporator coil to hang on the flange temporarily while the remaining attachment and sealing of the coil are performed.

#### **Return Air Connections**

The furnace and its return air system shall be designed and installed so that negative pressure created by the air circulating fan cannot affect another appliance's combustion air supply or act to mix products of combustion with circulating air. The air circulating fan of the furnace, if installed in an enclosure communicating with another fuel-burning appliance not of the direct-vent type, shall be operable only when any door or panel covering an opening in the furnace fan compartment or in a return air plenum on ducts is in the closed position.



3 0.9 34 1316 9 38.5 09 1089 3 46 6 871 8 37.6 7 57.4 7 785 6 41.6 2 575 8 56.5 14 1249 7 53.6	1.0  1335 38.0 1105 45.6 839 39.1 59.7 766 42.7 567 57.4 1251
9 38.5 9 1089  3 46 6 871 8 37.6 7 57.4 7 785 6 41.6  2 575 8 56.5  14 1249	38.0 1105  45.6 839 39.1 59.7 766 42.7  567 57.4  1251
9 38.5 99 1089  3 46 6 871 8 37.6 7 57.4 7 785 6 41.6  2 575 8 56.5  14 1249 	38.0 1105  45.6 839 39.1 59.7 766 42.7  567 57.4  1251
1089	1105  45.6 839 39.1 59.7 766 42.7  567 57.4  1251
3 46 6 871 8 37.6 7 57.4 7 785 6 41.6  2 575 8 56.5  14 1249	 45.6 839 39.1 59.7 766 42.7  567 57.4  1251
3 46 6 871 8 37.6 7 57.4 7 785 6 41.6  2 575 8 56.5  14 1249	45.6 839 39.1 59.7 766 42.7  567 57.4  1251
6 871 8 37.6 7 57.4 7 785 6 41.6  2 575 8 56.5  14 1249	839 39.1 59.7 766 42.7  567 57.4  1251
8 37.6 7 57.4 7 785 6 41.6  2 575 8 56.5  14 1249	39.1 59.7 766 42.7  567 57.4  1251
7 57.4 7 785 6 41.6  2 575 8 56.5  14 1249	59.7 766 42.7  567 57.4  1251
7 785 6 41.6  2 575 8 56.5  14 1249	766 42.7 567 57.4 1251
6 41.6 2 575 8 56.5 44 1249	42.7  567 57.4  1251
2 575 8 56.5  14 1249	567 57.4  1251
2 575 8 56.5  14 1249 	567 57.4  1251
8 56.5  14 1249 	57.4  1251 
 14 1249 	 1251 
1249	1251 
00.0	53.6
16 1024	1076
7 65.1	62.1
8 834	859
2 52.1	50.7
9 758	758
5 57.2	57.3
4 572	548
	1029
	43.3
	791
	54
	 597
-	
	345

Table 4 Air delivery - CFM (without filter) \* \*\*

A filter is required for each return air inlet. This table shows the airflow performance without a filter. To determine airflow performance with a filter, if a 3/4 inch (19 mm) washable media filter is used, assume an additional 0.1 in. WC available external static pressure.

 $<sup>^{\</sup>star\star}$  The manufacturer default fan settings are based on model, refer to Table 7.



Furnace	Return-air						Ext	ernal static p	ressure (in. V	VC)			
size	inlet	Speed		0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1.0
			CFM	1752	1764	1768	1781	1774	1786	1762	1802	1792	1786
		Н	Temp Rise-1st stage °F										
			Temp Rise-2nd stage °F	47.5	47.3	47.3	47.0	47.3	47.0	47.7	46.8	47.2	47.4
			CFM	1512	1506	1536	1523	1514	1509	1529	1551	1565	1532
			Temp Rise-1st stage °F	38.6	38.8	38.1	38.5	38.8	39	38.6	38.1	37.9	38.8
			Temp Rise-2nd stage °F	54.8	55.1	54.1	54.6	55.1	55.3	54.7	54.0	53.6	54.8
			CFM	1354	1354	1362	1370	1357	1381	1389	1394	1416	1383
100C	Bottom or Sides	Mid	Temp Rise-1st stage °F	42.9	43	42.8	42.6	43.1	42.4	42.3	42.2	41.7	42.7
	Sides	IVIIG			61.1	60.8	60.6	61.2	60.3	60.0	59.9	59.0	60.5
			Temp Rise-2nd stage °F	61.1									
		Mid-L	CFM	1165	1165	1176	1164	1185	1190	1186	1205	1174	1199
		IVIIQ-L	Temp Rise-1st stage °F	49.7	49.7	49.3	49.9	49.2	49.0	49.2	48.6	49.9	49.0
			Temp Rise-2nd stage °F CFM	994	1025	1018	1024	1032	1026	1035	988	1005	1041
		Low	Temp Rise-1st stage °F	58.1	56.4	56.9	56.6	56.3	56.7	56.3	59	58.1	56.2
		LOW	Temp Rise-2nd stage °F										
			CFM	1926	1926	1931	1943	1936	1941	1960	1974	2015	2043
		Н	Temp Rise-1st stage °F										
	Bottom or Sides		Temp Rise-2nd stage °F	43.2	43.3	43.2	43.1	43.3	43.3	42.9	42.7	42.0	41.6
			CFM	1746	1752	1749	1748	1749	1763	1771	1776	1794	1791
		Mid-H	Temp Rise-1st stage °F										
			Temp Rise-2nd stage °F	47.5	47.4	47.6	47.7	47.7	47.4	47.3	47.2	46.9	47.0
			CFM	1488	1525	1525	1515	1528	1546	1501	1525	1546	1544
100D		Mid	Temp Rise-1st stage °F	39	38.2	38.2	38.6	38.3	37.9	39.1	38.6	38.2	38.3
			Temp Rise-2nd stage °F	55.6	54.3	54.4	54.8	54.4	53.9	55.5	54.7	54.1	54.2
			CFM	1348	1374	1341	1383	1381	1385	1408	1404	1400	1401
		Mid-L	Temp Rise-1st stage °F	43.0	42.3	43.3	42.1	42.2	42.2	41.6	41.8	42.0	42.0
			Temp Rise-2nd stage °F	61.2	60.2	61.7	59.9	60.1	60	59.1	59.3	59.6	59.6
		Law	CFM	1163 49.7	1186	1164	1167 49.7	1174 49.5	1178 49.4	1182 49.3	1129 51.7	1163	1172 50
		Low	Temp Rise-1st stage °F Temp Rise-2nd stage °F	49.7	48.8	49.8	49.7	49.5	49.4	49.5	31.7	50.3	50
			CFM	1926	1933	1915	1923	1916	1929	1971	1941	2036	1998
		н	Temp Rise-1st stage °F										
			Temp Rise-2nd stage °F	51.8	51.7	52.2	52.1	52.4	52.1	51.1	52.0	49.8	50.7
			CFM	1721	1747	1716	1749	1760	1768	1778	1783	1747	1788
		Mid-H	Temp Rise-1st stage °F										
			Temp Rise-2nd stage °F	57.8	57.0	58.1	57.1	56.8	56.6	56.4	56.3	57.5	56.4
			CFM	1489	1497	1503	1504	1507	1488	1496	1518	1519	1568
120D	Bottom or Sides	Mid	Temp Rise-1st stage °F	46.7	46.6	46.4	46.5	46.5	47.1	47.0	46.4	46.4	45.1
	0.000		Temp Rise-2nd stage °F	66.5	66.3	66.1	66.1	66.1	67.0	66.7	65.8	65.9	64
			CFM	1384	1360	1365	1384	1382	1383	1379	1401	1421	1414
		Mid-L	Temp Rise-1st stage °F	50.2	51.1	51.0	50.4	50.6	50.6	50.8	50.1	49.5	49.9
			Temp Rise-2nd stage °F										
			CFM	1165	1175	1162	1158	1158	1184	1186	1204	1201	1185
		Low	Temp Rise-1st stage °F	59.5	59.0	59.8	60	60.1	58.9	58.9	58.1	58.4	59.2
			Temp Rise-2nd stage °F										

Table 5 Air delivery - CFM (without filter) \* \*\*

<sup>\*</sup> A filter is required for each return air inlet. This table shows the airflow performance without a filter. To determine airflow performance with a filter, if a 3/4 inch (19 mm) washable media filter is used, assume an additional 0.1 in. WC available external static pressure.

 $<sup>^{\</sup>star\star}$  The manufacturer default fan settings are based on model, refer to Table 7.

# 7.6 Blower Fan Speed Adjustment

To adjust the indoor blower fan speed, refer to the procedure below:

- 1. Turn OFF power to the furnace.
- 2. Select the heating and cooling blower speeds that match the installation requirements from Tables 4 & 5 Air Delivery CFM (Without Filter)\*
- If it is necessary to change the default settings, follow the below table to change S3 dip-switch to set appropriate fan speed.

	FAN SPEED						
Dip Switch Setting		DIP SWITCH POSITION	N.		NOMINA	L SPEED	
	S3-1	S3-2	S3-3	H-heat	L-heat	H-cool	L-cool
ON 1 2 3	OFF	OFF	OFF	4	2	2	2
ON 1 2 3	OFF	OFF	ON	4	2	3	2
ON 1 2 3	OFF	ON	OFF	4	3	3	2
ON 1 2 3	OFF	ON	ON	4	3	5	3
ON 1 2 3	ON	ON	ON	5	3	3	2
ON 1 2 3	ON	ON	OFF	5	3	4	3
ON 1 2 3	ON	OFF	ON	5	3	5	3
ON 1 2 3	ON	OFF	OFF	5	3	5	4

Table 6 Selectable Fan Speeds

- 4. Turn ON power to furnace.
- 5. Verify proper temperature rise is as outlined in Temperature Rise section and on the unit nameplate.



This furnace is equipped with an ECM constant airflow blower motor. The blower speed can be easily adjusted by the Dip Switch on the control board. Refer to Table 7 for blower speed factory default. These blower speeds should be adjusted by the installer to match the installation requirements so as to provide the correct heating temperature rise and the correct cooling CFM.

Model	HI COOL	LOW COOL	HI HEAT	LOW HEAT
60B	High(5)	Mid(3)	Mid-H(4)	Mid(3)
80B	High(5)	Mid-H(4)	High(5)	Mid(3)
80C	High(5)	Mid-H(4)	High(5)	Mid(3)
100C	Mid(3)	Mid-L(2)	Mid-H(4)	Mid-L(2)
100D	Mid(3)	Mid-L(2)	Mid-H(4)	Mid-L(2)
120D	Mid(3)	Mid-L(2)	Mid-H(4)	Mid(3)

Table 7 Factory default blower speed




Figure 24



Items in this section refer to the indoor blower fan, NOT to the induced draft blower. The induced draft blower speed is not adjustable. The indoor blower fan speed is adjustable.

As default, the indoor blower fan will remain on for 180 seconds after the gas valve closes. When a call for cooling occurs, the indoor blower fan comes on and remains on for 90 seconds after the call for cooling ends. During normal heating operation, the indoor blower fan will come on approximately 30 seconds after the gas valve opens.

# **Adjustment Switches**

DIP	NOMINAL (CECONDE)	
S2-1	S2-2	NOMINAL (SECONDS)
*OFF	OFF	90
ON	OFF	120
OFF	ON	150
ON	ON	180

Table 8 Heat OFF delay

DIP	NOMINAL (SECONDS)	
S2-3	S2-4	NOMINAL (SECONDS)
*OFF	OFF	60
ON	OFF	90
OFF	ON	120
ON	ON	150

Table 9 Cool OFF delay

<sup>\*</sup> factory default



# 8 Combustion Air and Vent System

# 8.1 Combustion Air and Vent Safety

This Category IV, dual certified (AHRI and ETL) direct vent furnace is designed for residential applications. It may be installed without modification to the condensate system in a basement, garage, equipment room, alcove, attic or any other indoor location where all required clearance to combustibles and other restrictions are met. The combustion air and the venting system must be installed in accordance with Section 5.3, Air for Combustion and Ventilation, of the National Fuel Gas Code Z223.1/NFPA 54 (latest edition), or Sections 7.2, 7.3 or 7.4 of CSA B149.1, National Gas and Propane Codes (latest edition) or applicable provisions of the local building code and these instructions.

#### NOTICE

### Product damage!

The "VENT SYSTEM" must be installed as specified in these instructions for Residential and Non HUD Modular Homes. The direct vent system is the only configuration that can be installed in a Non HUD Modular Home.



# **WARNING**

#### Carbon monoxide poisoning hazard!!

This furnace may not be vented with any other appliance. It requires separate, properly sized air intake and vent lines.

Do not discharge exhaust gases directly into any chimney or vent stack. If vertical discharge through an existing unused chimney or stack is required, insert piping inside chimney until the pipe open end is above top of chimney and terminate properly. In any exterior portion of chimney, the exhaust vent must be insulated.



# WARNING

#### Carbon monoxide poisoning hazard!!

When combustion air pipe is installed above a suspended ceiling or when it passes through a warm and humid space, the pipe must be insulated with 1/2" Armaflex or other heat resistant type insulation if two feet or more of pipe is exposed. Vent piping must be insulated if it will be subjected to freezing temperatures such as routing through unheated areas or through an unused chimney.



When two or more direct vent furnaces are vented near each other, each furnace must be individually vented. A minimum distance of 8 inches MUST be maintained.

# 8.2 Combustion Air/Vent Pipe Sizing

The size of pipe required will be determined by the furnace model, the total length of pipe required and the number of elbows required. Table 10, "Maximum Equivalent Pipe Length" lists the maximum equivalent length of pipe allowed for each model of furnace. The equivalent length of elbows is shown in Table 12, "Equivalent Length of Fittings".

The equivalent length of the vent system is the total length of straight pipe PLUS the equivalent length of all of the elbows. The following rules must also be followed:

- Long radius (sweep) elbows are recommended. Standard elbows may
  be used, but since they have a longer equivalent length, they will reduce
  the total length of pipe that will be allowed. Short radius (plumbing vent)
  elbows are not allowed. The standard dimensions of the acceptable elbows
  are shown below.
- The maximum equivalent length listed in Table 10, "Maximum Equivalent
  Pipe Length" is for the vent piping and the air intake piping separately. For
  example, if the table allows 60 equivalent feet for a particular model, then
  the vent can have 60 equivalent feet of pipe, AND the combustion air intake
  can have another 60 equivalent feet of pipe.
- Three vent terminal elbows (two for the vent and one for the combustion air intake) are already accounted for and need not be included in the equivalent length calculation.
- 4. All combustion air and vent pipes and fittings must conform to American National Standards Institute (ANSI) and American Society for Testing and Materials (ASTM) standards, D1785 (Schedule 40 PVC, including IPEX System 1738 Schedule 40 PVC), F441 (Schedule 40 CPVC), D2665 (PVC-DWV), F891 (PVC-DWV Cellular Core), D2661 (ABS-DWV) or D1527 (Schedule 40 ABS). Pipe cement and primer must conform to ASTM Standard D2564 (PVC), F493 (CPVC) or D2235 (ABS). If ABS pipe is to be used, any joint where ABS pipe is joined to PVC pipe must be glued with cement that is approved for use with BOTH materials. As an alternate, use all purpose cement, to bond ABS, PVC, or CPVC pipe when using fittings and pipe made of the same materials. Metallic materials must not be used for venting or air intake.
- If a flexible connector is used in the vent system, it must be made of a material that is resistant to acidic exposure and to at least 225° F temperature. Flexible connectors are also allowed in the combustion air pipe.
- 6. All models are supplied with 2" vent connections. When the pipe must be increased to 3" diameter, the transition from 2" to 3" must be done as close to the furnace as possible. For upflow models, the transition from 2" to 3" should be done immediately above the furnace. For downflow or horizontal models, the transition from 2" to 3" pipe should be done immediately after exiting the furnace.
- In Canada, vents shall be certified to ULC S636, Standard for Type BH Gas Venting Systems. IPEX System 636 PVC is certified to this standard.
- In Canada, the first three feet (900 mm) of the vent must be readily accessible for inspection.
- 9. Minimum vent length for all models is 5 feet.



For single pipe systems, it is recommended to install the provided combustion air coupling with approximately 18" of pipe on the furnace. In addition to the vent/flue pipe, a single 90° elbow should be secured to the combustion air intake to prevent inadvertent blockage.



Model Input Kbtu/h (kW)	Pipe Size Inches (cm)	Maximum Equivalent length ft (m)
60 (17.6)	2 (5.1)	40 (12.1)
60 (17.6)	3 (7.6)	90 (27.4)
80 (23.4)	2 (5.1)	N/A
80 (23.4)	3 (7.6)	90 (27.4)
100 (29.3)	2 (5.1)	30 (9.1)
100 (29.3)	3 (7.6)	70 (21.3)
120 (35.1)	2 (5.1)	N/A
120 (35.1)	3 (7.6)	50 (15.2)

Table 10 Maximum equivalent pipe length




Figure 25

Elbow	"A" Dimension
2" Standard	2-5/16"
3" Standard	3-1/16"
2" Sweep	3-1/4"
3" Sweep	4-1/16"

Table 11 Elbow dimensions

Fitting	Equivalent Length
2" 90° sweep elbow	5 feet of 2" pipe
2" 45° sweep elbow	2-1/2 feet of 2" pipe
2" 90° standard elbow	10 feet of 2" pipe
2" 45° standard elbow	5 feet of 2" pipe
3" 90° sweep elbow	5 feet of 3" pipe
3" 45° sweep elbow	2-1/2 feet of 3" pipe
3" 90° standard elbow	10 feet of 3" pipe
3" 45° standard elbow	5 feet of 3" pipe
2" corrugated connector	10 feet of 2" pipe
3" corrugated connector	10 feet of 3" pipe

Table 12 Equivalent length of fittings

#### Example:

A 60,000 BTUH furnace requires 32 feet of pipe and four  $90^{\circ}$  elbows. Using 2" pipe and standard elbows, the total equivalent length will be:

32 feet of 2" pipe =	32 equivalent feet
2 - 90° standard 2" elbows =	(2x10) = 20 equivalent feet
Total =	52 equivalent feet of 2" pipe

This exceeds the 40 foot maximum equivalent length of 2" pipe allowed for that model and is thus not acceptable.

By using sweep elbows, the total equivalent length will be:

32 feet of 2" pipe =	32 equivalent feet
4 - 90° sweep 2" elbows =	(4x5) = 20 equivalent feet
Total =	52 equivalent feet of 2" pipe

This exceeds the 40 foot maximum equivalent length of 2" pipe allowed for that model and is thus not acceptable.

Alternatively, using 3" pipe and standard elbows, the total equivalent length will be: 32 feet of 3" pipe = 32 equivalent feet  $4 - 90^{\circ} \text{ standard } 3" \text{ elbows} = (4x10)) = 40 \text{ equivalent feet}$  72 equivalent feet of 3" pipe

This is less than the 90 foot maximum equivalent length of 3" pipe allowed for that model and is thus acceptable.

Connection Type	Size - Inches (cm)
Intake Pipe	2" (5.1)
Vent Pipe	2" (5.1)

Table 13 Combustion air intake & vent connection size (all models)



Furnace vent pipe connections are sized for 2" (5.1 cm). pipe. Any pipe size change must be made outside the furnace cabinet in a vertical pipe section to allow proper drainage of condensate. An offset using two  $45^{\rm o}$  (degree) elbows will be required for plenum clearance when the vent is increased to 3" (7.6 cm).



# 8.3 Combustion Air And Vent Piping Assembly

The final assembly procedure for the combustion air and vent piping is as follows:

- 1. Cut piping to the proper length beginning at the furnace.
- 2. Deburr the piping inside and outside.
- 3. Chamfer (bevel) the outer edges of the piping.
- Dry-fit the vent piping assembly from the furnace to the outside termination checking for proper fit support and slope.
- Dry-fit the combustion air piping assembly checking for proper fit, support and slope on the following systems:
  - Sealed combustion air systems from the furnace to the outside termination.
  - b. Ventilated combustion air systems from the furnace to the attic or crawl space termination.



# **CAUTION**

#### Fire, explosion hazard!

Solvent cements are flammable and must be used in well-ventilated areas only. Keep them away from heat, sparks and open flames. Do not breathe vapors and avoid contact with skin and eyes.

- Disassemble the combustion air and vent piping, apply cement primer and the cement per the manufacturer's instructions. Primer and cement must conform to ASTM D2564 for PVC, F493 for CPVC or ASTM D2235 for ABS piping.
- 7. All joints must provide a permanent airtight and watertight seal.
- Support the combustion air and vent piping such that it is angled a
  minimum of 1/4" per foot (21 mm/m) so that condensate will flow back
  towards the furnace. Piping should be supported with pipe hangers to
  prevent sagging.
- Seal around the openings where the combustion air and / or vent piping pass through the roof or sidewalls.



# 8.4 Combustion Air / Venting

# **Vent Clearances**




Figure 26 Direct vent terminal clearances

Direct Vent Terminal Clearances	Canadian Installations 1,3	US Installation <sup>2,3</sup>
A. Clearance above grade, veranda, porch, deck, or balcony	12" (30.5 cm)	12" (30.5 cm)
B. Clearance to window or door that may be opened	12" (30.5 cm) for models <100,000 BTUH (30 kW), 36" (91 cm) for models >100,000 BTUH (30 kW)	Two-pipe (direct vent) applications: 9" (23 cm) for models <50,000 BTUH (15 kW), 12" (30.5 cm) for models >50,000 BTUH (15 kW). <sup>1†</sup> Single-pipe applications: 4 feet (1.2 m)
C. Clearance to permanently closed window	12" (30.5 cm)	12" (30.5 cm)
D. Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (61 cm) from the center line of the terminal	12" (30.5 cm) or in accordance with local installation codes and the requirements of the gas supplier	12" (30.5 cm) or in accordance with local installation codes and the requirements of the gas supplier
E. Clearance to unventilated soffit	12" (30.5 cm) or in accordance with local installation codes and the requirements of the gas supplier	12" (30.5 cm) or in accordance with local installation. codes and the requirements of the gas supplier
F. Clearance to outside corner	$12\mbox{\tt ''}$ (30.5 cm) or in accordance with local installation codes and the requirements of the gas supplier	12" (30.5 cm) or in accordance with local installation codes and the requirements of the gas supplier
G. Clearance to inside corner	36" (91.4 cm)	36" (91.4 cm)
H. Clearance to each side of center line extended above meter/regulator assembly	Above a meter/regulator assembly within 36" (91.4 cm) horizontally of the vertical center-line of the regulator vent outlet to a maximum vertical distance of 15 feet (4.5 m) above the meter/regulator assembly	Above a meter/regulator assembly within 36" (91.4 cm) horizontally of the vertical center-line of the regulator vent outlet to a maximum vertical distance of 15 feet (4.5 m) above the meter/regulator assembly
I. Clearance to service regulator vent outlet	36" (91.4 cm)	36" (91.4 cm) or in accordance with local installation codes and the requirements of the gas supplier
J. Clearance to nonmechanical air supply inlet to building or the combustion air inlet to any other appliance	12" (30.5 cm) for models <100,000 BTUH (30 kW), 36" (91.4 cm) for models >100,000 BTUH (30 kW).	Two-pipe (direct vent) applications: 9" (23 cm) for models <50,000 BTUH (15 kW), 12" (30.5 cm) for models >50,000 BTUH (15 kW) Single-pipe applications: 4 feet (1.2 m)
K. Clearance to a mechanical supply inlet	6 feet (1.83 m)	3 feet (91.4 cm) above if within 10 feet (3 m) horizontally
L. Clearance above paved sidewalk or paved driveway located on public property	7 feet (2.13 m) <sup>†</sup>	7 feet (2.13 m) or in accordance with local installation codes and the requirements of the gas supplier.
M. Clearance under veranda, porch, deck, or balcony	12" (30.5 cm)*	12" (30.5 cm) or in accordance with local installation codes and the requirements of the gas supplier

Table 14 Direct Vent Terminal Clearances

- $1.\ In\ accordance\ with\ the\ current\ CSA\ B149.1-00,\ Natural\ Gas\ and\ Propane\ Installation\ Code.$
- 2. In accordance with the current ANSI Z223.1 / NFPA 54, National Gas Code.
- 3. In accordance with the current ANSI Z21.47  $^{\star}$  CSA 2.3 American National Standard.
- <sup>†</sup> A vent shall not terminate directly above a sidewalk or paved driveway that is located between two single family dwellings and serves both dwellings.
- \*\* 12" (30.5 cm) up from the bottom edge of the structure for Two-pipe (direct vent) applications per ANSI 2223.1 / NFPA 54, Nat ional Gas Code.
- \* Permitted only if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor and the distance between the top of the vent termination and the underside of the veranda, porch, or deck is greater than 12" (30.5 cm) as specified in CSA B149.1-00.

A vent shall not terminate less than 12" (30.5 cm) above a grade level.

Any fresh air or make up inlet for dryer or fu rnace area is considered to be forced air inlet. Avoid areas where condensate dri ppage may cause problems such as above planters, patios, or adjacent to windows where steam may cause fogging.

A terminus of a vent shall be fitted with a cap in accordance with the vent manufacturer's installation instructions, or in acc ordance with the installation instructions for a special venting system. Responsibility for the provision of proper adequate venting and air supply for application shall rest with the installer.

Vent shall extend high enough above building, or a neighboring obstruction, so that wind from any direction will not create a positive pressure in the vicinity of the vent.





#### **CAUTION**

#### Fire, carbon monoxide poisoning hazard!

The vent must be installed with the minimum required clearances, and must comply with local codes and requirements.

#### NOTICE

#### Property damage!

Consideration must be given for degradation of building materials by flue gases. Sidewall termination may require sealing or shielding of building surfaces with a corrosion resistant material to protect against combustion product corrosion. Consideration must be given to wind direction in order to prevent flue products and/or condensate from being blown against the building surfaces. If a metal shield is used it must be a stainless steel material at a minimum dimension of 20 inches (51 cm). It is recommended that a retaining type collar be used that is attached to the building surface to prevent movement of the vent pipe.

#### 8.5 Vent System

This furnace is certified to be installed with one of two possible vent configurations.

- Horizontal vent system. This vent system can be installed completely horizontal or combinations of horizontal, vertical, or offset using elbows.
- Vertical vent system. This vent system can be installed completely vertical or a combination of horizontal, vertical, or offset using elbows.

# **Vent Applications And Termination**

When selecting the location for a horizontal combustion air / vent termination, the following should be considered:

- 1. Observe all clearances listed in vent clearances in these instructions.
- Termination should be positioned where vent vapors will not damage plants or shrubs or air conditioning equipment.
- Termination should be located where it will not be affected by wind gusts, light snow, airborne leaves or allow recirculation of flue gases.
- 4. Termination should be located where it will not be damaged or exposed to flying stones, balls, etc.
- 5. Termination should be positioned where vent vapors are not objectionable.
- Horizontal portions of the vent system must slope upwards and be supported to prevent sagging.
- Direct vent systems must be installed so the vent and the combustion air pipes terminate in the same atmospheric zone. Refer to Figures 27 or 28.




Figure 27 Termination configuration - 1 pipe




Figure 28 Termination configuration - 2 pipe




Figure 29 Termination configuration - 2 pipe basement

# **Venting Multiple Units**

Multiple units can be installed in a space or structure as either a single pipe configuration or a two-pipe configuration. The combustion air side of the single pipe configuration shown in Figure 28 is referred to in these instructions as ambient combustion air supply. Follow the instructions for ambient combustion air installations, paying particular attention to the section on air source from inside the building. The vent for a single pipe system must be installed as specified in the venting section of these instructions with the vent terminating as shown in Figure 27. Each furnace must have a separate vent pipe. Under NO circumstances can the two vent pipes be tied together.

If air from outside is brought in for combustion and ventilation, the confined space shall be provided with two permanent openings. The combustion air side of the two-pipe configuration shown in Figure 28 can be installed so the combustion air pipe terminates as described in outdoor combustion air or ventilated combustion air sections in these instructions.

Follow the instructions for outdoor combustion air or ventilated combustion air and the instructions for installing the vent system with the vent terminating as shown in Figures 30 or 31. The two-pipe system must have a separate combustion air pipe and a separate vent pipe for each furnace. Under NO circumstances can the two combustion air or vent pipes be tied together. The combustion air and vent pipes must terminate in the same atmospheric zone.






Figure 30 Double horizontal combustion air intake and vent termination




Figure 31 Double vertical combustion air intake and vent termination

When installing two or more Furnaces in the U.S, the termination vents must be a min. distance of 12" between termination vents. For Furnaces installed in Canada the termination vents need a distance of 12" if capacity is less than 100,000 BTU/h, and 36" for furnaces with more than 100,000 BTU/h.

Refer to figure 32 and 33.




Figure 32 Multiple concentric vent terminations clearance




Figure 33 Multiple flush mount vent terminations clearance

#### 8.5.1 Concentric Vent Termination Kit



SPECIAL VENTING REQUIREMENTS FOR INSTALLATIONS IN CANADA: Installation in Canada must conform to the requirements of CSA B149 code. Vent systems must be composed of pipe, fittings, cements, and primers listed to ULC S636. This concentric vent termination kit has been certified to ULC S636 for use with piping and vent components which have been certified to this standard. Follow the manufacturer's instructions in the use of primer and cement and never use primer or cement beyond its expiration date. The safe operation, as defined by ULC S636, of the vent system and this termination kit is based on following these installation instructions, the vent system manufacturer's installation instructions, and proper use of primer and cement. Acceptability under Canadian standard CSA B149 is dependent upon full compliance with all installation instructions. Under this standard, it is recommended that the vent system be checked once a year by qualified service personnel. The authority having jurisdiction (gas inspection authority, municipal building department, fire department, etc) should be consulted before installation to determine the need to obtain a permit.



#### **WARNING**

# Fire, explosion hazard!

These kits are to be used only for terminating condensing Category IV furnaces. DO NOT use kits to terminate Category I, II, or III vent furnaces. Failure to follow these instructions could result in fire, personal injury, or death.

Brand	K it No.	Description	Usage
DiversiTech	CVENT-2	2" x 35" Concentric Vent	US
DiversiTech	CVENT-3	3" x 39" Concentric Vent	US
IPEX	397005	2" x 16" Concentric Vent	US
IPEX	397105	2" x 28" Concentric Vent	US
IPEX	397125	2" x 40" Concentric Vent	US
IPEX	397006	3" x 20" Concentric Vent	US
IPEX	397106	3" x 32" Concentric Vent	US
IPEX	397116	3" x 44" Concentric Vent	US




Table 15 Concentric vent kits for U.S.



Brand	K it No.	Description	Usage
DiversiTech	CVENT-2CA	2" x 35" Concentric Vent	CAN
DiversiTech	CVENT-3CA	3" x 39" Concentric Vent	CAN
IPEX	196005	2" x 16" Concentric Vent	CAN
IPEX	196105	2" x 28" Concentric Vent	CAN
IPEX	196125	2" x 40" Concentric Vent	CAN
IPEX	196006	3" x 20" Concentric Vent	CAN
IPEX	196105	3" x 32" Concentric Vent	CAN
IPEX	196116	3" x 44" Concentric Vent	CAN



Table 16 Concentric vent kits for Canada

The concentric vent is made of PVC. When joining PVC to PVC, use cement that conforms to ASTM standard D2564. PVC primer must meet standard ASTM F656. When joining ABS to ABS, use cement that conforms to ASTM standard D2235. When joining PVC to ABS, use cement as specified in procedure from ASTM standard D3138.

In Canada, all plastic vent pipes and fittings including any cement, cleaners, or primers must be certified as a system to ULC S636. However this requirement does not apply to the finish flanges or piping internal to the furnace.

Consult your furnace installation instructions for the allowable length and size of the plastic vent pipe. The concentric vent termination assembly is equal to 4 feet of 3" inlet and outlet pipe, or 3 feet of 2" inlet and outlet pipe.

The concentric vent termination kit is shipped assembled but not cemented. Disassemble the kit and cement as shown in Tables 15 and 16.



# WARNING

#### Carbon monoxide poisoning hazard!

Do not operate the furnace with rain cap removed. Recirculation of combustion products may occur, or water may accumulate inside larger combustion air pipe and flow into the burner enclosure. Failure to follow this warning could result in product damage or improper operation, personal injury or death.



# WARNING

#### Carbon monoxide poisoning hazard!

DO NOT use field supplied couplings to extend pipes. Airflow restriction will occur and the furnace pressure switch may cause intermittent operation

#### **Roof Termination**

- Determine the best location for the termination kit. Refer to the Installation Instructions supplied with the furnace.
- Cut one hole, 5" diameter when using a 3" kit or a 4" diameter hole when using a 2" kit.
- Partially assemble the concentric vent termination kit as shown in Figure 34
  and Tables 15 and 16. Cement Y concentric vent fitting to larger diameter
  kit pipe. See Tables 15 and 16. Cement rain cap to smaller diameter kit
  pipe. See Tables 15 and 16.
- Install cemented Y concentric fitting and pipe assembly through structure's hole and field supplied roof boot/ flashing. See Figure 34.



Do not allow insulation or other materials to accumulate inside pipe assembly when installing through hole.

Secure assembly to roof structure using field supplied metal strapping or equivalent support material.



Make sure the termination height is above the roof surface or anticipated snow level (12 inches in U.S.A. or 18 inches in Canada). If the assembly is too short to meet the height requirement, the 2 pipes supplied in the kit may be replaced by using the same diameter, field supplied SDR-26 PVC (D2241) pipe. Do not expand dimension "D" more than 60 inches. See Figure 34.

- Cement field supplied furnace combustion air and vent pipes to concentric vent termination assembly.
- Run furnace through a complete heat cycle to ensure combustion air and vent pipes are properly connected to concentric vent termination connections.



Refer to section 7.2 for the proper inclination of the product and venting.




Figure 34



### **Side Wall Termination**

- Determine the best location for termination kit. Refer to the Installation Instructions supplied with the furnace.
- Cut one hole, 5" diameter if using a 3" kit or a 4" diameter hole if using 2" kit.
- Partially assemble the concentric vent termination kit as shown in Tables
   and 16. Cement Y concentric vent fitting to larger diameter kit pipe. b.
   Cement rain cap to smaller diameter kit pipe.
- Install cemented Y concentric fitting and pipe assembly through structure's hole (Figure 35). NOTE: Do not allow insulation or other materials to accumulate inside pipe assembly when installing through hole.
- Secure the assembly to the structure as shown in Figure 35 using field supplied metal strapping or equivalent support material.
- Cement field supplied furnace combustion air and vent pipes to concentric vent termination assembly.
- Run furnace through a complete heat cycle to ensure combustion air and vent pipes are properly connected to concentric vent termination connections.



# WARNING

### Product damage!

The exhaust pipe must be properly supported and pitched a minimum of 1/4" (6.35mm) per foot. This allows the condensate to properly drain.




Figure 35

### **Multiventing Terminations**

When two or more direct vent furnaces are vented near each other, each furnace must be individually vented. A minimum distance of 8 inches MUST be maintained.

### **Maximum Equivalent Pipe Length**

The maximum equivalent length listed in Table 17, "Maximum Equivalent Pipe Length" is for the vent piping and the air intake piping separately. For example, if the table allows 60 equivalent feet for a particular model, then the vent can have 60 equivalent feet of pipe, AND the combustion air intake can have another 60 equivalent feet of pipe.



Refer to Table 12 to calculate equivalent length of fittings.

Model Input Btu/h (kW)	Concentric Vent Kit, Pipe Size Inches (cm)	Maximum Equivalent length feet (m)
60 (17.6)	2 (5.1)	65 (19.8)
60 (17.6)	3 (7.6)	90 (27.4)
80 (23.4)	2 (5.1)	40 (12.1)
80 (23.4)	3 (7.6)	70 (21.3)
100 (29.3)	2 (5.1)	N/A
100 (29.3)	3 (7.6)	70 (21.3)
120 (35.1)	2 (5.1)	N/A
120 (35.1)	3 (7.6)	60 (18.2)

Table 17 Maximum equivalent pipe length for Concentric Vent Termination Kit



### 8.5.2 Flush-Mount Vent Termination Kit



### WARNING

### Personal injury or death!

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional installer (or equivalent), service agency or the gas supplier.



### WARNING

### Personal injury, carbon monoxide poisoning hazard, product damage!

Do not operate the furnace with rain cap removed. Recirculation of combustion products may occur, or water may accumulate inside larger combustion air pipe and flow into the burner enclosure. Failure to follow this warning could result in product damage or improper operation, personal injury or death.



### **CAUTION**

### Personal injury, carbon monoxide poisoning hazard, product damage!

Vent termination should be kept away from all sources of ignition.

DO NOT use field supplied couplings to extend pipes. Airflow restriction will occur and the furnace pressure switch may cause intermittent operation.

### **Application**

Termination kit is used to isolate intake and exhaust lines as they exit the wall of the structure. The kit may be used with either 2", 2-1/2" or 3" vent pipe.

### **Pipe & Fittings Specifications**

All pipe, fittings, primer and solvent cement must conform with American National Standard Institute and the American Society for Testing and Materials (ANSI/ASTM) standards. The solvent shall be free flowing and contain no lumps, undissolved particles or any foreign matter that adversely affects the joint strength or chemical resistance of the cement. The cement shall show no gelation, stratification, or separation that cannot be removed by stirring. Refer to Table 18 for approved piping and fitting materials.



# **WARNING**

# Fire, explosion hazard, personal injury!

Solvent cements for plastic pipe are flammable liquids and should be kept away from all sources of ignition.

Do not use excessive amounts of solvent cement when making joints. Good ventilation should be maintained to reduce fire hazard and to minimize breathing of solvent vapors. Avoid contact of cement with skin and eyes.

Piping and Fittings Specifications	
Schedule 40 PVC (Pipe)	D1785
Schedule 40 PVC (Cellular Core Pipe	F891
Schedule 40 PVC (Fittings)	D2466
Schedule 40 CPVC (Pipe)	F441
Schedule 40 CPVC (Fittings)	F438
SDR-21 PVC or SDR-26 PVC (Pipe)	D2241
SDR-21 CPVC or SDR-26 CPVC (Pipe)	F442
Schedule 40 ABS Cellular Core DWV (Pipe)	F628
Schedule 40 ABS (Pipe)	D1527
Schedule 40 ABS (Fittings)	D2468
ABS-DWV (Drain Waste & Vent) (Pipe & Fittings)	D2661
PVC-DWV (Drain Waste & Vent) Pipe & Fittings)	D2665
PRIMER & SOLVENT CEMENT	ASTM SPECIFICATION
PVC & CPVC Primer	F656
PVC Solvent Cement	D2564
CPVC Solvent Cement	F493
ABS Solvent Cement	D2235
PVC/CPVC/ABS All Purpose Cement For Fittings & Pipe of the same material	D2564, D2235, F493
ABS to PVC or CPVC Transition Solvent Cement	D3188
CANADA PIPE & FITTING & SOLVENT CEMENT	MARKING
PVC & CPVC Pipe and Fittings	
PVC & CPVC Solvent Cement	ULCS636
ABS to PVC or CPVC Transition Cement	
PVC & CPVC Solvent Cement	ULCS636

Table 18 Piping and fittings specifications

Use PVC primer and solvent cement or ABS solvent cement meeting ASTM specifications, refer to Table 1.As an alternate, use all purpose cement to bond ABS, PVC, or CPVC pipe when using fitings and pipe made of the same materials. Use transition solvent cement when bonding ABS to either PVC or CPVC.





Exhaust and intake connections are made of PVC. Use PVC primer and solvent cement when using PVC vent pipe. When using ABS vent pipe, use transitional solvent cement to make connections to the PVC fittings in the unit.

Low temperature solvent cement is recommended. Metal or plastic strapping may be used for vent pipe hangers. Uniformly apply a liberal coat of PVC primer for PVC or use a clean dry cloth for ABS to clean inside socket surface of fitting and male end of pipe to depth of fitting socket.

Canadian Applications Only - Pipe, fittings, primer and solvent cement used to vent (exhaust) this appliance must be certified to ULC S636 and supplied by a single manufacturer as part of an approved vent (exhaust) system.

### Installation



Take care when installing vent termination. Flue products may damage building materials, plants, shrubs or air conditioning equipment when vented too close to these items.

Position vent termination where prevailing winter winds will not cause recirculation of flue products. Position vent termination where it will not be damaged by foreign objects (rocks, balls etc.)

Refer to the units installation instructions for proper venting. This instruction is for installing the flush mount termination kit only.

- Determine the best location for the intake and exhaust piping to exit the wall. Exhaust and intake pipe must be free of any obstruction or blockage.
- 2. Exhaust vent pipe can be located horizontally left, right, or vertically up from the air intake pipe. See Fig. 36.
- Use the provided template to locate the intake and exhaust piping holes and four screw holes.
- 4. Using the template as a guide, drill two 3-5/8" holes for 3" PVC pipe or two 2-1/2" holes for 2" PVC and 2-1/2" PVC pipe. For 2-1/2" PVC installations transition to 2"PVC and install into flush-mount as shown in Fig.39. Do not vary from the template. All dimensions are critical. There must be 4" center line to center line for either 3" pipe or 2" pipe. See Fig.37.
  - If installing on a masonry or brick wall, drill four 9/32" diameter holes for the provided anchors. If a portion of a brick or masonry wall must be removed, repair as needed. If installing on a wood wall and NOT using the provided anchors, drill four 1/8" pilot holes.
- 5. When determining pipe length, include the length of exhaust and intake pipes that extend beyond the wall and are flush into the flush mount termination. For 3" pipe add an extra inch to the overall length. For 2" pipe add an extra 2" to the overall length. See Fig. 38.
- The 1-1/2" accelerator must be used for all unit installations. Fully insert and glue the accelerator (flat side first) into the 2" exhaust opening. See Fig.38.
- 7. Install the intake pipe and exhaust pipe through the holes drilled in step 4 and into the flush mountterminaiton. Exhaust pipe may be glued but it is not necessary. See Fig. 38. Seal all openings as indicated in Fig. 39.
- Secure the flush-mount termination to the wall using the provided screws and anchors or field-provided screws if applicable. See Fig. 40. Termination should be flush against the wall as shown in Fig. 39.




Figure 36





Figure 37 Mounting template

Brand	K it No.	Description	Usage
DiversiTech	HVENT-2	2" Dia. Horizontal Termination Kit	US
DiversiTech	HVENT-3	3" Dia. Horizontal Termination Kit	US
IPEX	397984	2" Dia. Low Profile Termination Kit	US
IPEX	397985	3" Dia. Low Profile Termination Kit	US

Table 19 Flush mount kit for U.S.

Brand	K it No.	Description	Usage
DiversiTech	CVENT-2CA	2" x 35" Concentric Vent	CAN
DiversiTech	CVENT-3CA	3" x 39" Concentric Vent	CAN
IPEX	196005	2" x 16" Concentric Vent	CAN
IPEX	196105	2" x 28" Concentric Vent	CAN

Table 20 Flush mount kits for Canada






Figure 38 Figure 40




Figure 39 Typical installation



### 8.6 Combustion & Ventilation Air Requirements

# 8.6.1 Combustion Air Supply

All installations must comply with Section 5.3, Air for Combustion and Ventilation of the National Fuel Gas Code, ANSI Z223.1 or Sections 7.2, 7.3 or 7.4 of CAN/CGA B149.1 or .2 Installation Code - latest editions.

This furnace is certified to be installed with one of three possible combustion air intake configurations.

### 1. Outdoor Combustion Air:

This is a direct vent configuration where the combustion air is supplied through a PVC, CPVC or ABS pipe that is connected to the PVC coupling attached to the furnace and is terminated in the same atmospheric zone as the vent. This type of installation is approved on all models. Refer to Figure 30.

#### 2. Ambient Combustion Air:

Combustion air is supplied from the area surrounding the furnace through openings in the furnace cabinet. The combustion air and the vent pipes are not terminated in the same atmospheric zone. Refer to Figure 28 for vent terminations. Refer to Section "Ambient Combustion Air Supply" for proper installation. Refer to Figure 30.

#### 3. Ventilated Combustion Air:

Combustion air is supplied through a PVC, CPVC or ABS pipe that is connected to the PVC coupling attached to the burner box and is terminated in a ventilated attic or crawl space. The combustion air and the vent pipes are not terminated in the same atmospheric zone. Refer to Figure 31 for attic and crawl space termination. Only the combustion air intake may terminate in the attic. The vent must terminate outside.

### 8.6.2 Outdoor Combustion Air

### **Combustion Air Intake/Vent Connections**

This installation requires combustion air to be brought in from outdoors. This requires a properly sized pipe (shown in Figure 41) that will bring air in from the outdoors to the furnace combustion air intake collar on the burner box. The second pipe (Shown in Figure 41) is the furnace vent pipe.




Figure 41 Direct vent air intake connection and vent connection

The combustion air intake pipe should be located either through the wall (horizontal or side vent) or through the roof (vertical vent). Care should be taken to locate side vented systems where trees or shrubs will not block or restrict supply air from entering the terminal. Also, the terminal assembly should be located as far as possible from a swimming pool or a location where swimming pool chemicals might be stored. Be sure the terminal assembly follows the outdoor clearances listed in Table 14.

### 8.6.3 Ambient Combustion Air

This type of installation will draw the air required for combustion from within the space surrounding the appliance and from areas or rooms adjacent to the space surrounding the appliance. This may be from within the space in a non-confined location or it may be brought into the furnace area from outdoors through permanent openings or ducts. It is not piped directly into the furnace. A single, properly sized pipe from the furnace vent connector to the outdoors must be field supplied.



### **WARNING**

# Carbon monoxide poisoning hazard!

f It is recommended that the supplied intake coupling and 18" of pipe be attached to the furnace to prevent accidental blockage of the combustion air intake.




Figure 42 Combustion Airflow Path Through The Furnace Cabinet




Figure 43 Ambient Combustion Air



### **WARNING**

### Carbon monoxide poisoning hazard!

This type of installation requires that the supply air to the appliance(s) be of a sufficient amount to support all of the appliance(s) in the area. Operation of a mechanical exhaust, such as an exhaust fan, kitchen ventilation system, clothes dryer or fireplace may create conditions requiring special attention to avoid unsatisfactory operation of gas appliances. A venting problem or a lack of supply air will result in a hazardous condition, which can cause the appliance to soot and generate dangerous levels of CARBON MINOXIDE, which can lead to serious injury, property damage and/or death.

An **unconfined space** is not less than 50 cu.ft (1.42m3) per 1,000Btu/hr (0.2928 kW) input rating for all of the appliances installed in that area. Rooms communicating directly with the space containing the appliances through openings not furnished with doors are considered a part of the unconfined space. In unconfined spaces (see definition below) in buildings, infiltration may be adequate to provide air for combustion ventilation and dilution of flue gases. However, in buildings of tight construction (for example, weather stripping, heavily insulated, caulked, vapor barrier, etc.), additional air may need to be provided using the methods described in "A confined space" section.

A **confined space** is an area with less than  $50\,\mathrm{cu}$ . It  $(1.42\,\mathrm{m}3)$  per  $1,000\,\mathrm{Btu/hr}$  ( $0.2928\,\mathrm{kW}$ ) input rating for all of the appliances installed in that area. The following must be considered to obtain proper air for combustion and ventilation in confined spaces.

# **Equipment Located in Confined Spaces:**

### a) All air from inside the building:

The confined space shall be provided with two permanent openings communicating directly with an additional room(s) of sufficient volume so that the combined volume of all spaces meets the criteria. The total input of all gas utilization equipment installed in the combined space shall be considered in making this determination. Each opening shall have a minimum free area of 1 square inch per 1,000 BTU per hour of the total input rating of all gas utilization equipment in the confined space. One opening shall be within 12 inches of the top and one within 12 inches of the bottom of the enclosure (See Table 21).

BTUH Input Rating	Minimum Free Area in Square Inch Required for Each Opening
60,000	60 sq.in (387 sq.cm)
80,000	80 sq.in (516 sq.cm)
100,000	100 sq.in (645 sq.cm)
120,000	120 sq.in (775 sq.cm)

Table 21 Minimum Area in Square Inches Required for Each Opening

### b) All air from outdoors:

	Minimum Free Area Required for Each Opening								
BTUH Input Rating	Input Horizontal Duct	Vertical Duct or Opening to Outside (4,000 BTUH)	Round Duct (4,000 BTUH)						
60,000	30 sq.in (193 sq.cm)	15 sq.in (97 sq.cm)	5" (13 cm)						
80,000	40 sq.in (258 sq.cm)	20 sq.in (129 sq.cm)	5" (13 cm)						
100,000	50 sq.in (323 sq.cm)	25 sq.in (161 sq.cm)	6" (15 cm)						
120,000	60 sq.in (387 sq.cm)	30 sq.in (194 sq.cm)	7" (18 cm)						

Table 22 Minimum Area in Square Inch Required for Each Opening

### **EXAMPLE: Determining Free Area.**

Appliance 1 Appliance 2 Total Input  $100,000 + 30,000 = (130,000 \div 4,000) = 32.5$  Sq. In. Vertical

Appliance 1 Appliance 2 Total Input 100,000 + 30,000 = (130,000 ÷ 2,000) = 65 Sq. In. Horizontal



### Air Supply Openings and Ducts

- An opening may be used in lieu of a duct to provide the outside air supply
  to an appliance unless otherwise permitted by the authority having
  jurisdiction. The opening shall be located within 12" (30.5 cm) horizontally
  from the burner level of the appliance.
- The duct shall be either metal or a material meeting the class 1 requirements of CAN4-S110 Standard for Air Ducts.
- The duct shall be at least the same cross-sectional area as the free area of the air supply inlet opening to which it connects.
- The duct shall terminate within 12 in (30.5 cm) above, and within 24 in (61 cm) horizontally from, the burner level of the appliance having the largest input.
- A square or rectangular shaped duct shall only be used when the required free area of the supply opening is 9 in 2 (58.06 cm 2) or larger. When a square or rectangular duct is used, its small dimension shall not be less than 3 in (7.6 cm).
- An air inlet supply from outdoors shall be equipped with a means to prevent the direct entry of rain and wind. Such means shall not reduce the required free area of the air supply opening.
- 7. An air supply inlet opening from the outdoors shall be located not less than 12 in (30.5 cm) above the outside grade level.

### **Combustion Air Source from Outdoors**

- Two permanent openings, one within 12 in (305 mm) of the top and one within 12 in (305 mm) of the bottom of the confined space, shall communicate directly or by means of ducts with the outdoors, crawl spaces or attic spaces.
- 2. One permanent opening, commencing within 12 in (305 mm) of the top of the enclosure shall be permitted where the equipment has clearances of at least 1 in (25.4 mm) from the sides and back and 6 in (152.4 mm) from the front of the appliance. The opening shall communicate directly with the outdoors and shall have a minimum free area of:
  - a. 1 square inch per 3000 Btu per hour (734 mm2/kW) of the total input rating of all equipment located in the enclosure.
  - b. Not less than the sum of all vent connectors in the confined space.
- The duct shall be at least the same cross-sectional area as the free area of the air supply inlet opening to which it connects.
- The blocking effects of louvers, grilles and screens must be given consideration in calculating free area. If the free area of a specific louver or grille is not known, refer to Table 23, "Estimated Free Area" to estimate free area.

Wood or Metal Louvers or Grilles	Wood 20-25%, Metal 60-70%
Screens	1/4" mesh or larger 100%

Table 23 Estimated Free Area

### 8.6.4 Ventilated Combustion Air

The ventilated attic space or a crawl space from which the combustion air is taken must comply with the requirements specified in "Combustion Air Source from Outdoors" in this instruction or in Section 7.4, Air for Combustion and Ventilation of the National Fuel Gas Code, ANSI Z223.1 (latest edition). This type in stallation requires two properly sized pipes. One brings combustion air from a properly ventilated attic space or crawl space and a second pipe that extends from the furnace vent connection (top right of unit) to the exterior of the building.



# 8.7 Vent and Supply (Outside) Air Safety Check Procedure

For Category IV furnaces, vent installations shall be in accordance with Parts 7 and 11 of the National Fuel Gas Code, ANSI Z223.1/NFPA 54 and/or Section 7 and Appendix B of the CAS B 149.1, Natural Gas and Propane Installation Codes, the local building codes, and furnace/vent manufacture's instructions. Multi-story systems must be installed in accordance with the National Fuel Gas Code, ANSI Z223.1/NFPA 54 and / or the CSA B 149.1, Natural Gas and Propane Installation Codes, and the manufacturer's instructions.

Horizontal portions of the venting system shall be supported to prevent sagging using hangers or perforated straps and must slope upwards no less than 1/4 in. per foot (0.635 cm/m) from the furnace to the vent terminal. It is recommended that you follow the venting safety procedure below. This procedure is designed to detect an inadequate ventilation system that can cause the appliances in the area to operate improperly causing unsafe levels of Carbon Monoxide or an unsafe condition to occur.




Figure 44 Attic and Crawl Space Combustion Air Termination

### **Specially Engineered Installations**

The above requirements shall be permitted to be waived where special engineering, approved by the authority having jurisdiction, provides an adequate supply of air for combustion and ventilation.



### Carbon monoxide poisoning hazard!

Be sure to instruct the owner not to block this intake pipe.

# $\hat{}$

# **WARNING**

### Carbon monoxide poisoning hazard!

Failure to follow the steps outlined below for each appliance connected to the venting system being placed into operation could result in carbon monoxide poisoning or death. The following steps shall be followed for each appliance connected to the venting system being placed into operation, while all other appliances connected to the venting system are not in operation:

- Inspect the venting system for proper size and horizontal pitch. Determine that there is no blockage, restriction, leakage, corrosion or other deficiencies which could cause an unsafe condition.
- 2. Close all building doors and windows and all doors.
- Turn on clothes dryers and TURN ON any exhaust fans, such as range hoods and bathroom exhausts, so they shall operate at maximum speed.
   Open the fireplace damper. Do not operate a summer exhaust fan.
- Follow the lighting instructions. Place the appliance being inspected in operation. Adjust thermostat so the appliance shall operate continuously.
- 5. Test each appliance (such as a water heater) equipped with a draft hood for spillage (down-draft or no draft) at the draft hood relief opening after 5 minutes of main burner operation. Appliances that do not have draft hoods need to be checked at the vent pipe as close to the appliance as possible. Use a combustion analyzer to check the CO2 and CO levels of each appliance. Use a draft gauge to check for a downdraft or inadequate draft condition.
- After it has been determined that each appliance properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas burning appliance to their normal condition.
- 7. If improper venting is observed during any of the above tests, a problem exists with either the venting system or the appliance does not have enough combustion air (Supply Air from outside) to complete combustion. This condition must be corrected before the appliance can function safely. NOTE: An unsafe condition exists when the CO reading exceeds 40 ppm and the draft reading is not in excess of -0.1 in. W.C.(-25 kPa) with all of the appliance(s) operating at the same time.
- 8. Any corrections to the venting system and / or to the supply (outside) air system must be in accordance with the National Fuel Gas Code Z223.1 or CAN/CGA B149.1 Natural Gas and Propane Installation Code (latest editions). If the vent system must be resized, follow the appropriate tables in Appendix G of the above codes or for this appliance.



# 9 Gas Supply and Piping



# WARNING

### Fire or explosion hazard!

Never purge a gas line into a combustion chamber. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections.



### WARNING

### Fire or explosion hazard!

Use proper length of pipe to avoid stress on gas control manifold and to prevent a gas leak.



# **CAUTION**

### Furnace overheat hazard!

Connect gas pipe to gas valve using a backup wrench to avoid damaging gas controls and to avoid burner misalignment.



# WARNING

### Fire or explosion hazard!

If local codes allow the use of a flexible gas appliance connector, always use a new listed connector. Do not use a connector which has previously served another gas appliance. Black iron pipe shall be installed at the furnace gas control valve and extend a minimum of 2 inches outside the furnace.

### 9.1 General

The furnace rating plate includes the approved furnace gas input rating and gas types. The furnace must be equipped to operate on the type of gas applied. This includes any conversion kits required for alternate fuels and/or high altitude.

Inlet gas supply pressures must be maintained within the ranges specified in Table 24. The supply pressure must be constant and available with all other household gas-fired appliances operating. The minimum gas supply pressure must be maintained to prevent unreliable ignition. The maximum must not be exceeded to prevent unit overfiring.

	Inlet Gas Supply Pressure						
Natural Gas	Minimum: 4.5 in. WC	Maximum:10.5 in. WC					
Propane Gas	Minimum:11.0 in. WC	Maximum:13.0 in. WC					

Table 24 Inlet Gas Supply Pressure

### NOTICE

### Product damage!

Adjusting the minimum supply pressure below the limits in Table 24 could lead to unreliable ignition. Gas input to the burners must not exceed the rated input shown on the rating plate. Overfiring of the furnace can result in premature heat exchanger failure. Gas pressures in excess of 13 in. WC can also cause permanent damage to the gas valve.

At all altitudes and with either fuel (natural gas or LP), the air temperature rise must be within the range listed on the furnace nameplate. Should this appliance be converted to LP, refer to the instructions included in the factory authorized natural gas to LP conversion kit.



# 9.2 High Altitude Derate

Alternately, in high altitude applications, a standard derate for altitude from National Fuel Gas Code ANSI Z223.1 of 4% per 1000 feet above sea level may be taken. Refer to the most recent version of ANSI Z223.1 for correct gas orifice based on your specific application. The orifices must be selected using the specifications listed in the table below. The furnace derate is 4% for each 1,000 feet above sea level.

Table 25 is based upon a heating value of approximately 1,000 Btu/ft3.

In Canada, the input rating must be derated by 10 percent for altitudes of 2,000 ft. to 4,500 ft. above sea level by an authorized Gas Supplier or Dealer.

When an appliance is installed at elevations above 4500 ft, the certified highaltitude input rating shall be reduced at the rate of 4% for each additional 1000 ft.

In some areas the gas supplier may artificially derate the gas in an effort to compensate for the effects of altitude. If the gas is artificially derated, the appropriate orifice size must be determined based upon the BTU/ft³ content of the derated gas and the altitude. Refer to the latest version of NFPA54/ANSI Z223.1 and information provided by the gas supplier to determine the proper orifice size.

#### **US** installation

Input Rate KBTU/H N		Elevation (Ft)		Elevation (Ft)		Elevation (Ft)		Elevation (Ft)		Elevation (Ft)	
	Number of burners	0-2000		2000-4000		4000-6000		6000-8000		8000-10000	
		NG**	LP*								
60	3	45	55	47	56	48	57	49	58	50	59
80	4	45	55	47	56	48	57	49	58	50	59
100	5	45	55	47	56	48	57	49	58	50	59
120	6	45	55	47	56	48	57	49	58	50	59

Table 25 High Altitude Derate Orifice Size Chart (Natural and LP Gas\*)

- \* LP orifice based on 10 in. WC manifold pressure
- The input to the furnace must be checked AFTER reorificing.

### **Canada installation**

Input Rate Number of bur KBTU/H		Elevation (Ft) 0-2000		Elevation (Ft) 2000-4000		Elevation (Ft) 4000-6000		Elevation (Ft) 6000-8000		Elevation (Ft)	
	Number of burners									8000-10000	
		NG**	LP*	NG**	LP*	NG**	LP*	NG**	LP*	NG**	LP*
60	3	45	55	47	56	48	57	49	58	50	59
80	4	45	55	47	56	48	57	49	58	50	59
100	5	45	55	47	56	48	57	49	58	50	59
120	6	45	55	47	56	48	57	49	58	50	59

Table 26 High Altitude Derate Orifice Size Chart (Natural and LP Gas\*)

- \* LP orifice specification based on 10 in. WC manifold pressure (as specified on the unit's rating plate for LP).
- The input to the furnace must be checked AFTER reorificing.
- \*\* NG denotes natural gas



For Canada applications, regulation requires 10% derating between 2000-4500 ft. When an appliance is installed at elevations above 4500 ft, the certified high altitude input rating shall be reduced at the rate of 4% for each additional 1000 ft.

<sup>\*\*</sup> NG denotes natural gas



# 9.3 Propane Gas (LP) Conversion



# WARNING

# Fire or explosion hazard!

Possible property damage, personal injury or death may occur if the correct conversion kits are not installed. The appropriate kits must be applied to ensure safe and proper furnace operation. All conversions must be performed by a qualified installer or service agency.

This unit is configured for natural gas. However, all furnaces come standard with a conversion kit for propane gas (LP). The appropriate manufacturer's propane gas conversion kit must be applied for propane gas (LP) installations. For high altitude installations (above 2000 ft), refer to the "High Altitude Derate" section for details.

The indicated kits must be used to ensure safe and proper furnace operation. All conversions must be performed by a qualified installer, or service agency. Refer to the installation instructions supplied with the conversion kit.

# 9.4 Gas Piping Connections

To avoid possible unsatisfactory operation or equipment damage due to underfiring of equipment, use the proper size of natural/propane gas piping needed when running pipe from the meter/tank to the furnace.

When sizing a trunk line, be sure to include all appliances which will operate simultaneously (see Table 27).

The gas piping supplying the furnace must be properly sized based on the gas flow required, specific gravity of the gas, and length of the run. The gas line installation must comply with local codes, or in their absence, refer to the latest version of NFPA54/ANSI Z223.1.

Nominal iron Int	Internal DIA.	Length of pipe-ft							
pipe size in.	in.	10	20	30	40	50			
1/2	0.622	175	120	97	82	73			
3/4	0.824	360	250	200	170	151			
1	1.049	680	465	375	320	285			
1-1/4	1.380	1400	950	770	660	580			
1-1/2	1.610	2100	1460	1180	990	900			

Table 27 Natural Gas Capacity of Pipe in Cubic Feet of Gas Per Hour (CFH)

(Pressure 0.5 psig or less and pressure drop of 0.3 in. WC; Based on 0.60 Specific Gravity Gas)

To connect the furnace to the building's gas piping, the installer must supply a ground joint union, drip leg, manual shutoff valve, and line and fittings to connect to gas valve. In some cases, the installer may also need to supply a transition piece from 1/2" pipe to a larger pipe size.



The following stipulations apply when connecting gas piping.

- · Use black iron or steel pipe and fittings for the building piping.
- Use pipe joint compound on male threads only. Pipe joint compound must be resistant to the action of the fuel used.
- · Use ground joint unions.
- Install a drip leg to trap dirt and moisture before it can enter the gas valve.
   The drip leg must be a minimum of three inches long.
- Install a 1/8" NPT pipe plug fitting, accessible for test gauge connection, immediately upstream of the gas supply connection to the furnace.
- Use two pipe wrenches when making connection to the gas valve to keep it from turning. The orientation of the gas valve on the manifold must be maintained as shipped from the factory.
- Install a manual shutoff valve between the gas meter and unit within six feet of the unit. If a union is installed, the union must be downstream of the manual shutoff valve, between the shutoff valve and the furnace.
- · Tighten all joints securely.
- Connect the furnace to the building piping by one of the following methods:
  - 1. Rigid metallic pipe and fittings.
  - Semi-rigid metallic tubing and metallic fittings. Aluminum alloy tubing must not be used in exterior locations.
  - Use listed gas appliance connectors in accordance with their instructions. Connectors must be fully in the same room as the furnace.
  - The installation of piping shall be in accordance with piping codes and the regulations of the local gas company. Pipe joint compound must be resistant to the chemical reaction with liquefied petroleum gases.

When the gas piping enters through the right side of the furnace, the installer must supply the following fittings (starting from the gas valve):

- 90 degree elbows (2).
- Close nipple.
- Straight pipe to reach the exterior of the furnace.

A ground joint union, drip leg, and manual shutoff valve must also be supplied by the installer. In some cases, the installer may also need to supply a transition piece from 1/2" to another pipe size.

When the gas piping enters through the left side of the furnace, the installer must supply the following fittings (starting from the gas valve):

- Straight pipe to reach the exterior of the furnace.
- A ground joint union, drip leg, and manual shutoff valve must also be supplied by the installer. In some cases, the installer may also need to supply a transition piece from 1/2 inch to another pipe size.




Figure 45 Typical Gas Pipe Arrangement

# 9.5 Gas Piping Checks

Before placing unit in operation, leak test the unit and gas connections.



# Fire or explosion hazard!

Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections.

Check for leaks using an approved chloride-free soap and water solution, an electronic combustible gas detector, or other approved testing methods.

# NOTICE

# Product damage!

Never exceed specified pressures for testing. Higher pressures may damage the gas valve and cause subsequent overfiring, resulting in heat exchanger failure.

Disconnect this unit and shutoff valve from the gas supply piping system before pressure testing the supply piping system with pressures in excess of 1/2 psig (3.48 kPa)

This furnace must be isolated from the gas supply system by closing its manual shutoff valve before pressure testing of gas supply piping system with test pressures equal to or less than 1/2 psig (3.48 kPa).



### 10 Electrical Connections



# WARNING

### **Electrical shock hazard!**

Blower access panel door switch opens 115V power to control. No component operation can occur. Do not bypass or close the blower access panel door switch with panel removed.

Refer to Figure 48 and 49 for field wiring diagram showing typical field 115V wiring. Check all factory and field electrical connections for tightness. Field-supplied wiring shall conform with the limitations of 63°F (35°C) rise.



### **WARNING**

### **Electrical shock, fire hazard!**

The cabinet MUST have an uninterrupted or unbroken ground according to NEC ANSI/NFPA 70-latest edition or local codes to minimize personal injury if an electrical fault should occur.

This may consist of electrical wire, conduit approved for electrical ground or a listed, grounded power cord (where permitted by local code) when installed in accordance with existing electrical codes. Refer to the power cord manufacturer's ratings for proper wire gauge. Do not use gas piping as an electrical ground.

### NOTICE

#### Furnace may not operate!

Furnace control must be grounded for proper operation or else control will lock out. Control must remain grounded through green/yellow wire routed to gas valve and manifold bracket screw.

# 10.1 115V Wiring

Verify that the voltage, frequency, and phase correspond to that specified on unit rating plate. Also, check to be sure that service provided by utility is sufficient to handle load imposed by this equipment. Refer to rating plate or Table 28 for equipment electrical specifications.

Make all electrical connections in accordance with National Electrical Code (NEC) ANSI/NFPA 70-latest edition and any local codes or ordinances that might apply.

**U.S. installations:** Make all electrical connections in accordance with National Electrical Code (NEC ANSI/NFPA 70-2008 and any local codes or ordinances that might apply. Canadian installations: Make all electrical connections in accordance with Canadian Electrical Code CSA C22.1 or authorities having jurisdiction.



# WARNING

# Fire hazard!

Do not connect aluminum wire between disconnect switch and furnace. Use only copper wire.

Use a separate, fused branch electrical circuit with a properly sized fuse or circuit breaker for this furnace. See Table 28 for wire size and fuse specifications. A readily accessible means of electrical disconnect must be located within sight of the furnace.



Proper polarity must be maintained for 115V wiring. If polarity is incorrect, control LED status indicator light will flash rapidly and furnace will NOT operate.

### Junction box relocation



If factory location of J-Box is acceptable, go to next section **Electrical Connection** to **J-box**.



On 14" wide cabinet models, the J-Box shall not be relocated to other side of furnace cabinet when the vent pipe is routed within the cabinet.

1. Remove and save two screws holding J-Box (See Figure 46).



The J-Box cover need not be removed from the J-Box in order to move the J-Box. Do NOT remove green ground screw inside J-Box. The ground screw is not threaded into the cabinet flange and can be lifted out of the clearance hole in cabinet while swinging the front edge of the J-Box cover away from the cabinet.

- 2. Cut wire tie on loop in furnace wires attached to J-box
- 3. Move J-Box to desired location
- 4. Fasten J-Box to cabinet with two screw removed in Step 1.
- Route J-Box wires within furnace away from sharp edges, rotating parts and hot surfaces.




Figure 46 J-Box



### 10.2 Electrical Connection to J-box

# Field-Supplied Electrical Box on Furnace J-Box Bracket

See Fig. 46 on previous page.

- 1. Remove cover from furnace J-Box.
- Attach electrical box to furnace J-Box bracket with at least two fieldsupplied screws through holes in electrical box into holes in bracket. Use blunt-nose screws that will not pierce wire insulation.
- Route furnace power wires through holes in electrical box and J-Box bracket, and make field-wire connections in electrical box. Use best practices (NEC in U.S.) for wire bushings, strain relief, etc.
- Route and secure field ground wire to green ground screw on J-Box bracket, OR FURNACE WILL FAIL TO OPERATE.
- 5. Connect line voltage leads as shown in Fig. 48.
- 6. Reinstall cover to J-Box. Do not pinch wires between cover and bracket.

### **Electrical Box on Furnace Cabinet Side.**



### **WARNING**

### Fire, electrical shock hazard!

If field-supplied manual disconnect switch is to be mounted on furnace cabinet side, select a location where a drill or fastener cannot damage electrical or gas components.

 Select and remove a knockout hole in the cabinet where the electrical box is to be installed.



Check that duct on side of furnace will not interfere with installed electrical box.

- Remove the desired electrical box hole knockout and position the hole in the electrical box over the hole in the furnace cabinet.
- Fasten the electrical box to cabinet by driving two field-supplied screws from inside electrical box into cabinet steel.
- 4. Remove and save two screws holding J-Box. (See Fig. 46.)
- Pull furnace power wires out of 1/2-inch diameter hole in J-Box. Do not loosen wires from strain-relief wire-tie on outside of J-Box.
- 6. Route furnace power wires through holes in cabinet and into electrical box.
- 7. Pull field power wires into electrical box.
- 8. Remove cover from furnace J-Box.
- Route field ground wire through holes in electrical box and cabinet, and into furnace J-Box.
- 10. Reattach furnace J-Box to furnace cabinet with screws removed in Step 4.
- 11. Secure field ground wire to green ground screw on J-Box Bracket.
- Complete electrical box wiring and installation. Connect line voltage leads as shown in Figure 48 or 49. Use best practices (NEC in U.S. and CSA C22.1 in Canada) for wire bushings, strain relief, etc.
- 13. Reinstall cover to J-Box. Do not pinch wires between cover and bracket.

# 10.3 Power Cord Installation in Furnace J-box



Power cords must be able to handle the electrical requirements listed in Table 28. Refer to power cord manufacturer's listings.

- 1. Remove cover from J-Box.
- 2. Route listed power cord through 7/8-inch diameter hole in J-Box.
- Secure power cord to J-Box bracket with a strain relief bushing or a connector approved for the type of cord used.
- 4. Secure field ground wire to green ground screw on J-Box bracket.
- 5. Connect line voltage leads as shown in Fig. 48.
- 6. Reinstall cover to J-Box. Do not pinch wires between cover and bracket.

### 10.4 BX Cable Installation in Furnace J-box

- 1. Remove cover from J-Box.
- 2. Route BX cable into 7/8-inch diameter hole in J-Box.
- Secure BX cable to J-Box bracket with connectors approved for the type of cable used.
- 4. Secure field ground wire to green ground screw on J-Box bracket.
- 5. Connect line voltage leads as shown in Fig. 48.
- 6. Reinstall cover to J-Box. Do not pinch wires between cover and bracket.

# 10.5 24V Wiring

Low-voltage wires include indoor unit connect with outdoor unit and the indoor unit connect with the thermostats.

The wires between the indoor unit and the outdoor unit are classified into two modes: PQ communication and conventional 24VAC non-communicating thermostat control.

PQ communication mode is the factory default setting. Refer to Section 10.9 for more details on 24V Wiring.

The 24V circuit contains an automotive-type, 5-Amp. fuse located on the control. Any direct shorts during installation, service, or maintenance could cause this fuse to blow. If fuse replacement is required, use ONLY a 5-Amp. fuse of identical size.

### 10.6 Accessories (Field Supplied)

### 1. Electronic Air Cleaner (EAC)

For connection to an Electronic Air Cleaner (if needed), use ¼-inch female quick connect terminals to engage with the two ¼-inch male quick connect terminals on the control board marked EAC-H and one of NEUTRALS. The terminals are rated for 115 VAC, 1.0 amps maximum and are energized when blower motor is in operation (see Figure 47).

### 2. Humidifier (HUM)

Connect an accessory humidifier using the ½-inch male quick connect terminals marked HUM and one of NEUTRALS, respectively, on the control board. The HUM is energized when gas valve relay is energized. The terminals are rated for 115VAC, 1.0 amps maximum (See Figure 47).

# 10.7 Grounding

The furnace must be electrically grounded in accordance with local codes or, in the absence of local codes, with the National Electrical Code, ANSI/NFPA 70, if an external electrical source is utilized.



Inp	Input		Output		MAX. Unit Amps	AFUE	Air Temp. Rise		Max. Over-Current Protection	Min. Wire Size (AWG) @ 75 ft	Max. Outle	et Air Temp
MBH	kW	MBH LP	kW	CFM			°F LP	°C	Amps		°F	°C
60B3	17.6	57	16.4	1200	8	96	30-60	17-33	15	14	160	71
80B3	23.4	76	22.3	1200	8	96	35-65	19-36	15	14	165	74
80C4	23.4	76	22.3	1600	7.8	96	35-65	19-36	15	14	165	74
100C5	29.3	95	27.8	2000	11.5	96	35-65	19-36	20	14	165	74
100D5	29.3	95	27.8	2000	10.5	96	35-65	19-36	20	14	165	74
120D5	35.2	106.5	33.7	2000	10.5	95	40-70	22-39	20	14	170	77

Table 28 Ratings & Physical / Electrical Data

 $\label{thm:condition} Annual Fuel Utilization \ Efficiency \ (AFUE) \ numbers \ are \ determined \ in \ accordance \ with \ DOE \ Test \ procedures.$ 

National Electrical Code (NFPA-70-latest edition) and all local codes.

The furnace shall be installed so that the electrical components are protected from water.

# **Optional Switch Positions**

DIP Sv	NOMINAL		
S1-1	S1-2	(MINUTES)	
OFF	OFF	OFF*	
ON	OFF	10	
OFF	ON	AUTO	
ON	ON	20	

Table 29 W2 Delay

<sup>\*</sup> The factory default settings

DIP St	DIP Switch (SW)		
S2-1	S2-2	(SECONDS)	
OFF	OFF	90*	
ON	OFF	120	
OFF	ON	150	
ON	ON	180	

Table 30 Heat Off Delay

<sup>\*</sup> The factory default settings

DIP Sv	NOMINAL	
\$2 <b>-</b> 3	S2-4	(SECONDS)
OFF	OFF	60*
ON	OFF	90
OFF	ON	120
ON	ON	150

Table 31 Cool Off Delay

<sup>\*</sup> The factory default settings






Figure 47 Furnace Control






Figure 48 Low Voltage Wiring Diagram - Communicating Mode (default)




Figure 49 Low Voltage Wiring Diagram - Non-communicating Mode



# 10.8 Refrigerant Leakage Sensors



# WARNING

### Fire or explosion hazard!

According to the safety requirements of UL 60335-2-40 on combustible refrigerant A2L, when the gas furnace is used with coil using combustible refrigerant, the unit must be equipped with the refrigerant gas detection sensor to monitor the refrigerant concentration around the unit in real time to prevent the danger of abnormal refrigerant leakage.

Refrigerant gas detection sensors are manufactured under the coil manufacturing label and must be installed by a qualified local gas supplier, distributor or service organization.

If the refrigerant gas detection sensor is not installed or is incorrectly installed, it does not meet the requirements of current regulations and cannot effectively warn of an emergency, which may cause personal injury. Therefore, follow the instructions provided in the manual.

### Installation of refrigerant gas detection sensor:

When installed with a Bosch BMAC Series R-454B Cased Coil, plug the refrigerant sensor cable into the CN30 port on the Main Control Board (see Figure 47). Ensure the Dip Switch SW1-2 is set to "ON" position. Refer to the coil manual for installation locations of refrigerant gas sensors.

# **LED2 Flashing Troubleshooting:**

Refer to the table below for fault statuses related to the refrigerant sensor:

LED2 Number of green flashes	Fault Description	Fault Cause	Troubleshooting Steps
1	R454B Refrigerant Sensor Communication Fault	The communication with the refrigerant sensor fails for 2 minutes	Check if the sensor is plugged in correctly Replace the refrigerant sensor and restart the unit
2	Refrigerant Leak Protection	There is an active refrigerant leak	Check for puntures in the refrigerant circuit and perform repair or replacement. Check for natural gas/propane leak, maintain ventilation and avoid open flames. Replace the refrigerant if a leak is not found.
3	Dip Switch Setting Does Not Match R454B Refrigerant Sensor	The sensor is connected and communication is normal, but SW1-2 is in the "OFF" position	Check whether SW1-2 is set to "ON" position
4	R454B Refrigerant Sensor Over Serivce Life	The sensor is operating over the designed service lifetime	Replace the refrigerant sensor and restart the unit

Table 32



# 10.9 Thermostat Settings and Wiring

# 10.9.1 Thermostat Settings

The Thermostat should be set to either Fossil Fuel or Dual Fuel.




Figure 50

2. The Fan control logic should be set to "Appliance" control.




Figure 51

# 10.9.2 Thermostat Wiring - Furnace Only Application (Fossil Fuel)

1. Wiring with two stage thermostat




Figure 52

2. Wiring with single stage thermostat




Figure 53



# 10.9.3 Thermostat Wiring - Dual Fuel Application, Communicating Setup Dip switch configurations for communicating mode (default)




Figure 54



Communicating mode will only function when the RevC BGH96 Series Furnace is installed with certain R-454B Bosch IDS Condensers. Please refer to the Condenser IOM to confirm whether communication capability is supported.

PQ communication supports non-polar communication.

If there are 2 or more systems (communication) in the same area, make sure the low voltage wires are connected to the right unit that are connected to the same refrigerant line.

# Low voltage wire connections with outdoor unit, communicating

Connect the two field supplied wires to the PQ wiring terminal on the electric control box next to the fan module board.

# a. Wiring with 4H/2C thermostat




Figure 55

# b. Wiring with 3H/2C thermostat




Figure 56





PQ communication mode and conventional 24VAC non-communicating thermostat control mode can not be used at the same time.

# NOTICE

# Product damage!

Do not interconnect different communication wires or conventional 24VAC non-communicating thermostat control wires (PQ, CBYW, etc.), otherwise it will damage the control board. The following example shows incorrect wiring.




Figure 57

# 10.9.4 Thermostat Wiring - Dual Fuel application, Non-Communicating Setup Dip switch configurations for non-communicating mode




Figure 58



Conventional 24VAC non-communication mode is not the factory default for this system. See Figure 58 to ensure the unit is set to non-communication mode.

The RevC BGH96 Series Furnace can be configured to non-communicating mode when there are constraints that do not allow a communicating setup.

# Low voltage wire connections with outdoor unit, non-communicating

- Remove the wire connecting CN5 on the main control board and CN12 on the fan module board.
- Take out the 24VAC non-communication wires from the accessory bag and plug it into CN5 on the main control board.
- Connect the 24VAC non-communication wires to the four field supplied wires and connect the thermostat control wires to the thermostat wiring terminal on the main control board.
- Set SW1-3 to "OFF". If installed with a Bosch IDS Condenser, ensure the Dip Switch SW5-4 is also configured to non-communicating mode. Refer to the Condenser Installation Manual.



# a. Wiring with 4H/2C thermostat




Figure 59

# b. Wiring with 3H/2C thermostat




Figure 60



# 11 Start-Up, Adjustment, and Safety Check

# 11.1 General



### **WARNING**

# Fire or explosion hazard!

This furnace is equipped with manual reset limit switches in the gas control area. The switches open and shut off power to the gas valve if a flame rollout or overheating condition occurs in the gas control area. DO NOT bypass the switches. Correct inadequate combustion air supply problem before resetting the switches.



### **CAUTION**

### **Cut hazard!**

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses, and gloves when handling parts and servicing furnaces.

- Maintain 115V wiring and ground. Improper polarity will result in rapid flashing LED and no furnace operation (See Figure 48 and 49).
- Make thermostat wire connections at the 24V terminal block on the furnace control. Failure to make proper connections will result in improper operation (See Figure 48 and 49).
- Gas supply pressure to the furnace must follow Table 24 "Inlet Gas Supply Pressure" in Section 9.1.
- 4. Check all manual-reset switches for continuity.
- Install blower and burner access panels. Panels must be in place to operate furnace.

# 11.2 Start-Up Procedures



### **WARNING**

# Fire or explosion hazard!

Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections.

- 1. Purge gas lines after all connections have been made.
- 2. Check gas lines for leaks.



# WARNING

### Electrical shock hazard!

Blower access panel switch opens 115V power to control. No component operation can occur unless the switch is closed. Caution must be taken when manually closing this switch for service purposes.

3. This furnace is also equipped with a self-diagnosing electronic control module. In the event a furnace component is not operating properly, the control module LED will flash on and off in a factory programmed sequence depending on the problem encountered. This light can be viewed through the sight glass on the blower access panel. Refer to the Troubleshooting Chart (Tables 37 & 38) for further explanation of the lighting codes. Follow the start-up and adjustment items in Section 11. Refer to Section 12 for further information on Operational Checks.

# 11.3 Furnace Start-Up

- Close the manual gas shutoff valve external to the furnace.
- 2. Turn off the electrical power to the furnace.
- 3. Set the room thermostat to the lowest possible setting.
- 4. Remove the burner access panel.



### WARNING

### Fire or explosion hazard!

This furnace is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.

- 5. Push the gas valve switch to the OFF position.
- 6. Wait five minutes to clear out any gas. Then check for gas leaks around the furnace
- If odor of natural gas is detected following the five minute waiting period, repeat step 6. If gas odor persists after more than 10 minutes, check for leaks using a soap and water solution.
- 8. If odor of gas is not detected after five minutes, push the gas valve switch to the ON position.



# WARNING

# Fire or explosion hazard!

Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections.

- 9. Replace the burner access panel on the front of the furnace.
- 10. Open the manual gas valve external to the furnace.
- 11. Turn on the electrical power supply to the furnace.
- Set the room thermostat to slightly above room temperature. After some delay, the furnace will start.
- Refer to Section 11.4 "Sequence of Operation" for specific details on how the furnace operates.



There is an approximate 37 second delay between thermostat energizing and burner firing.



### Furnace shutdown

In case of furnace malfunction, use the following steps to shut the unit down:

- 1. Set the thermostat to OFF or it's lowest temperature setting.
- 2. Turn off the electrical power supply to the furnace.
- 3. Remove the burner access panel.
- 4. Close manual gas shutoff valve external to the furnace.
- 5. Push the gas valve switch to the OFF position.
- 6. Replace burner access panel.

### 11.4 Sequence of Operation



Furnace control must be grounded for proper operation or control will lock out. Control is grounded through green/yellow wire routed to gas valve and manifold bracket screw. Follow the sequence of operation through the heating, cooling, and fan only modes.

Read and follow the wiring diagram (Fig. 66) very carefully.

The blower access panel must be installed for power to be conducted through all electrical components.

### 1. Heating mode

In a typical system, a call for first stage heat is initiated by closing the W1 thermostat contacts. The inducer blower is energized at high speed and the control waits for the low pressure switch contacts to close. The humidifier (optional) is also energized at this time. Once the low pressure switch contacts close, a 15-second pre-purge is initiated. Then the inducer changes to low speed and the 115 V ignitor is powered. At the end of the ignitor warm-up time, the first stage of the two-stage manifold gas valve is energized (low fire). Flame must be detected within 4 seconds. If flame is detected, the 30-second HEAT delay-to-fan-on period begins. After the delay-to-fan-on period ends, the control will energize the circulator fan at low heat speed. The electronic air cleaner (optional) will also energize at this time.

For a two-stage thermostat, a call for second stage heat (W1 and W2) after a call for first stage heat will energize the inducer at high speed and the circulator at high heat speed. The second stage pressure switch contacts will close and energize the second stage gas valve (high fire). For a single-stage thermostat, when a call for heat occurs (W1), a 10, 20 minute or auto mode heat staging timer will be activated (timing is selectable with option switches S1-1 and S1-2 positions). Following this delay, the second stage heat is energized as above. The AUTO model algorithm is a method of energizing the second stage gas valve based on the recent average of the heating duty cycle. During a typical heating day, the low to high stage delay is determined by using the average calculated duty cycle from the table below. Once the specified delay time has expired the second stage valve will be energized. See the table below for the different duty cycles.

Average Calculated Duty Cycle % Equals	Or less than	Low to High Stage Delay	Demand
0	38	12 minutes	Light
38	50	10 minutes	Light to Average
50	62	7 minutes	Average
62	75	5 minutes	Average to Heavy
75	88	3 minutes	Heavy Light
88	100	1 minutes	Heavy

Table 33 Duty Cycles

When the second stage of the thermostat is satisfied, the inducer motor is reduced to low speed and the second stage gas valve is de-energized. On the control, the circulator will remain at high heat speed for 30 seconds following the opening of the second stage gas valve and then is reduced to low heat speed. When the first stage of the thermostat is satisfied, the first stage gas valve is de-energized and the HEAT delay-to-fan-off begins timing. The inducer will postpurge for an additional 15 seconds, then the inducer and humidifier will turn off. Upon completion of the HEAT delay-to-fan-off period, the circulator is turned off. The electronic air cleaner on the control is also de-energized at this time.

If flame is not detected during the trial-for-ignition period or if the flame is detected/sensed and then lost before completion of 10 seconds of establishment, the gas valve is de-energized, the ignitor is turned off, and the control goes into the "retry" sequence. The "retry" sequence provides a 60-second wait with the inducer interpurge following an unsuccessful ignition attempt (flame not detected). After this wait, the ignition attempt is restarted. Two retries will be attempted before the control goes into system lockout. If flame is established for more than 10 seconds after ignition, the controller will clear the ignition attempt (or retry) counter. If flame is lost after 10 seconds, the control will restart the ignition sequence. A momentary loss of gas supply, flame blowout, or a shorted or open condition in the flame probe circuit will be sensed within 2 seconds. The gas valve will deenergize and the control will restart the ignition sequence. Recycles will begin and the burner will operate normally if the gas supply returns, or the fault condition is corrected, before the last ignition attempt. Otherwise, the control will go into system lockout. If the control has gone into system lockout, it may be possible to reset the control by a momentary power interruption of 10 seconds or longer.



### **Timing specifications**

(All times are in seconds, unless noted otherwise)

(All times are in seconds, unless noted otherwise)					
Event	Definition	Time (Seconds)			
Pre-purge Time	The period of time intended to allow for the dissipation of any unburned gas or residual products of combustion at the beginning of a furnace operating cycle prior to initiating ignition	15			
Ignitor Warm-up Time	The length of time allowed for the ignitor to heat up prior to the ignition of gas flow.	17			
Trial for ignition Period(TFI)	The period of time between initiation of gas flow and the action to shut off the gas flow in the event of failure to establish proof of the supervised ignition source or the supervised main burner flame.	4			
Ignition Activa- tion Period(IAP)	The period of time between energizing the main gas vale and deactivation of the ignition means prior to the end of TFI	3			
Retries	The additional attempts within the same thermostat cycle for ignition when the supervised main burner flame is not proven within the first trial for ignition period.	2 times			
Valve Sequence period	Value sequence period equals 4 seconds trial for ignition period x (1 initial try + 2 retries)+12 seconds.	12			
Inter-purge	The period of time intended to allow for the dissipation of any unburned gas or residual products of combustion between the failed trial for ignition and the retry period.	60			
Post-purge Time	The period of time intended to allow for the dissipation of any unburned gas or residual products of combustion at the end of a furnace burner operating cycle, Post-purge begins at the loss of flame sense.	15			
Lock-Out Time	ANSI standard rated module timing.	300			
Heat Delay-To- Fan-On	The period of time between proof of the supervised main burner flame and the activation of the blower motor at heat speed.	30			
Heat Delay-To- Fan-Off*	The period of time between the loss of a call for heat and the deactivation of the blower motor at Heat speed.	*90/120/ 150/180			
Cool Delay-To- Fan-On	The period of time after a thermostat demand for cool before energizing the circulator blower motor at cool speed.	1			
Cool Delay-To- Fan-Off	The period of time between the loss of a call for cool and the deactivation of the blower motor at cool speed.	60/*90/ 120/150			
Automatic Reset Time	After one (1) hour of internal or external lockout, the control will automatically reset itself and go into an auto restart purge for 60 seconds.	60 minutes			

# Table 34

When using a single stage thermostat, second stage delay is based on the setting of switch S1-1, S1-2 shown below.

### Option Switches S1-1 & S1-2 Positions

DeleviTime	On "S1" set switch #		
Delay Time:	1	2	
Off*	Off	Off	
10 min	On	Off	
Auto min	Off	On	
20 min	On	On	

Table 35 2nd Stage Delay For Single Stage Thermostats

# 2. Cooling Mode (if applicable)

In a typical single stage cooling system (Y connection), a call for cool is initiated by closing the thermostat contacts. This energizes the compressor and the electronic air cleaner (optional).

The circulator will be energized at cool speed after the COOL delay-to-fan-on period. After the thermostat is satisfied, the compressor is de-energized and the COOL delay-to-fan-off period begins. After the COOL delay-to-fan-off period ends, the circulator and the electronic air cleaner are de-energized.

### 3. FAN Mode

If the thermostat fan mode is set to ON, the circulator fan (low heat speed) and optional electronic air cleaner are energized. When the fan mode is returned to AUTO, the circulator fan and electronic air cleaner (optional) are deenergized.

# 11.5 Gas Manifold Pressure Measurement and Adjustment

### NOTICE

# Improper operation, product damage!

To prevent unreliable operation or equipment damage, the gas manifold pressure must be as specified on the unit rating plate. Only minor adjustments should be made by adjusting the gas valve pressure regulator.

This valve is shipped from the factory with the regulator preset to 3.5 in. WC. Consult the appliance rating plate to ensure burner manifold pressure is as specified. If another outlet pressure is required, follow these steps (see Table 36 and Fig. 61):

- 1. Turn OFF all electrical power to the system.
- Using a 3/32 inch hex wrench, loosen outlet pressure tap screw one turn. Do not remove screw.
- Attach a hose and manometer to the outlet pressure barb fitting of valve to overlap at least 3/8"
- 4. Turn ON system power and set thermostat to a call for heat.
- Using a leak detection solution or non-chlorine soap suds, check for leaks at hose connection. Bubbles forming indicate a leak. SHUT OFF GAS AND FIX ALL LEAKS IMMEDIATELY!
- Remove burner access panel.
- Remove regulator screw cover. Turn regulator screw either clockwise to increase pressure or counter clockwise to decrease. Always adjust regulator to provide the correct pressure according to the original equipment manufacturer specifications listed on the appliance rating plate.
- Replace regulator screw cover and finger-tighten securely.
- 9. Turn OFF all electrical power to the system.

<sup>\*</sup> These times will vary depending on dip switch setting.

<sup>\*</sup> Factory default setting- two stage thermostat



- 10. Remove manometer and hose from outlet pressure tap.
- 11. Tighten outlet pressure tap clockwise 7 in-lbs minimum to seal port.
- 12. Replace burner access panel.
- 13. Turn ON system power and set thermostat to call for heat.
- 14. Using a leak detection solution or non-chlorine soap suds, check for leaks at hose connection. Bubbles forming indicate a leak. SHUT OFF GAS AND FIX ALL LEAKS IMMEDIATELY!




Figure 61 Gas valve and regulator adjustment

 Measure gas manifold pressure with burners firing. Adjust manifold pressure per the Manifold Gas Pressure table.

# 11.6 Gas Input Rate Measurement (Natural Gas Only)

The gas input rate to the furnace must never be greater than that specified on the unit rating plate. To measure natural gas input using the gas meter, use the following procedure.

- Turn OFF the gas supply to all other gas-burning appliances except the furnace.
- While the furnace is operating, time and record one complete revolution of the smallest gas meter dial.
- Calculate the number of seconds per cubic foot (sec/ft³) of gas being delivered to the furnace. If the dial is a one cubic foot dial, divide the number of seconds recorded in step 2 by one. If the dial is a two cubic foot dial, divide the number of seconds recorded in step 2 by two.
- 4. Calculate the furnace input in BTUs per hour (BTU/hr). Input equals the installation's gas heating value multiplied by a conversion factor (hours to seconds) divided by the number of seconds per cubic foot. The measured input must not be greater than the input indicated on the unit rating plate.

#### Example:

Installation's gas heating (HTG) value: 1,000 BTU/ft³ (Obtained from gas supplier) Installation's seconds per cubic foot: 34 sec/ft³

Conversion Factor (hours to seconds): 3600 sec/hr

Input = (Htg. value x 3600) + seconds per cubic foot

Input = (1,000 BTU/ft3 x 3600 sec/hr) + 34 sec/ft3

Input = 106,000 BTU/hr

This measured input must not be greater than the input indicated on the unit rating plate.

Turn ON gas and relight appliances turned off in step 1. Ensure all the
appliances are functioning properly and that all pilot burners are operating.

In most Datin a MDTII/II	Furna an Mardal	Pressure Setting				Orifice Size	
Input Rating KBTU/H	Furnace Model	Natural Gas LO	Natural Gas HI	Propane LO	Propane HI	Natural Gas	Propane Gas
60	BGH96M060B3C	1.6" W.C	3.5" W.C	6" W.C	10" W.C	45	55
80	BGH96M080B3C	1.6" W.C	3.5" W.C	6" W.C	10" W.C	45	55
80	BGH96M080C4C	1.6" W.C	3.5" W.C	6" W.C	10" W.C	45	55
100	BGH96M100C5C	1.6" W.C	3.5" W.C	6" W.C	10" W.C	45	55
100	BGH96M100D5C	1.6" W.C	3.5" W.C	6" W.C	10" W.C	45	55
120	BGH96M100D5C	1.6" W.C	3.5" W.C	6" W.C	10" W.C	45	55

Table 36 Manifold Gas Pressure



The gas valve regulator is factory configured for Natural Gas. To adjust the gas manifold pressure, carefully turn the plastic regulator adjustment screw counterclockwise. To restore factory setting, first fully tighten the regulator adjustment screw clockwise, then carefully turn the screw counterclockwise for 2-3 turns until manifold pressure reading matches Table 36.

The final manifold pressure must not vary more than  $\pm\,0.3$  in. WC from specified manifold pressure.

Any necessary major changes in gas flow rate should be made by changing the size of the burner orifice.

# 11.7 Temperature Rise Adjustment

Air temperature rise is the temperature difference between supply and return air. The proper amount of temperature rise is usually obtained when the unit is operated at the rated input with the "as shipped" blower speed. If the correct amount of temperature rise is not obtained, it may be necessary to change the blower speed.

# NOTICE

### Improper operation, product damage!

An incorrect temperature rise can cause condensing in or overheating of the heat exchanger. Determine and adjust the temperature rise as follows. The temperature rise must be within the range specified on the rating plate.

### **Temperature Rise Adjustment**

- Operate furnace with burners firing for approximately 15 minutes. Ensure all registers are open and all duct dampers are in their final (fully or partially open) position.
- Place thermometers in the return and supply ducts as close to the furnace as possible. Thermometers must not be influenced by radiant heat by being able to "see" the primary heat exchanger (see Figure 62).
- Subtract the return air temperature from the supply air temperature to determine the air temperature rise. Allow adequate time for thermometer readings to stabilize.
- Adjust temperature rise by adjusting the circulator blower speed. Increase blower speed to reduce temperature rise. Decrease blower speed to increase temperature rise. Refer to the following section for speed changing details.




Figure 62 Temperature rise measurement



# 12 Operational Checks



### **DANGER**

# Fire, explosion, electrical shock, and carbon monoxide poisoning hazard!

To avoid personal injury or death. Do not remove any internal component covers or attempt any adjustment. Electrical compartments are contained in both compartments. Contact a qualified service technician at once if an abnormal flame appearance should develop.

#### **Burner Flame**

The burner flames should be inspected with the burner access panel installed. Flames should be stable, quiet, soft, and blue (dust may cause orange tips but they must not be yellow). Flames should extend directly outward from the burners without curling, floating, or lifting off, and should enter heat-exchanger tube. Flames must not impinge on the sides of the heat exchanger firing tubes.




Figure 63 Burner Flame

# 13 Safety Circuit Description

### 13.1 General

A number of safety circuits are employed to ensure safe and proper furnace operation. These circuits serve to control any potential safety hazards and serve as inputs in the monitoring and diagnosis of abnormal function. These circuits are continuously monitored during furnace operation by the integrated control module.

### 13.2 Integrated Control Module

The integrated control module is an electronic device which controls all furnace operations. Responding to the thermostat, the module initiates and controls normal furnace operation, and monitors and addresses all safety circuits. If a potential safety concern is detected, the module will take the necessary precautions and provide diagnostic information through an LED.

### 13.3 Primary Limit

The primary limit control is located on the partition panel and monitors heat exchanger compartment temperature. It is an automatic reset, temperature sensor. The limit guards against the overheating resulting from insufficient air passing over the heat exchanger.

# 13.4 Rollout Limits

The rollout limit controls are mounted on the burner/manifold assembly and monitor the burner flame. They are manual-reset, temperature sensors. This limit guards against burner flames not being properly drawn into the heat exchanger.

### 13.5 Reverse Flow Limits

The reverse flow limit control is located on the blower scroll and monitors heat exchanger compartment temperature. It is an automatic reset, temperature sensor. The limit guards against the overheating resulting from insufficient air passing over the heat exchanger.

# 13.6 Overflow Protection Pressure Switch (Overflow Switch)

Overflow switch is a differential pressure switch. The shape and dimension of the overflow switch is similar to the two other pressure switches except it has two pressure ports, one in gray color (negative) and the other in black color (positive). The overflow switch is normally closed. When condensate hoses/trap is blocked and condensate is stopped flowing to drain system, the level of condensate inside the condensate collector box will rise. When the condensate reaches too high of a level in condensate collector box, the overflow switch will open and shut off the furnace. Make sure that black port (positive) is connected to the lower position tap on the condensate collector box and gray port (negative) to higher tap of condensate box. The manufacturer's default setting is for upflow and horizontal right installations only. For horizontal left installation, hoses for overflow switch are required to switch (see horizontal left installation). Connecting hoses incorrectly will result in failure to protect condensate overflow.

### 13.7 Pressure Switches

The pressure switches are normally open, negative air pressure activated switches. They monitor the airflow (combustion air and flue products) through the heat exchanger via pressure taps located on the induced draft blower. These switches guard against insufficient airflow (combustion air and flue products) through the heat exchanger.

### 13.8 Flame Sensor

The flame sensor is a probe mounted to the burner/manifold assembly which uses the principle of flame rectification to determine the presence or absence of flame.



### **WARNING**

# Fire, explosion, electrical shock, and carbon monoxide poisoning hazard!

This appliance uses a NEGATIVE PRESSURE REGULATED gas control. Replace ONLY with the same model number or as specified by the manufacturer.



# 14 Troubleshooting

# 14.1 Electrostatic Discharge (ESD) Precautions

### NOTICE

### Product damage!

Discharge body's static electricity before touching unit. An electrostatic discharge can adversely affect electrical components.

Use the following precautions during furnace installation and servicing to protect the integrated control module from damage. By equalizing the electrostatic potential between the furnace control and the person, these steps will help avoid exposing the integrated control module to electrostatic discharge. This procedure is applicable to both installed and uninstalled (ungrounded) furnaces.

- Disconnect all power to the furnace. Do not touch the integrated control
  module or any wire connected to the control prior to discharging your
  body's electrostatic charge to ground.
- Firmly touch a clean and unpainted metal surface of the furnace away from the control. Any tools held in a person's hand during grounding will be discharged.
- Service integrated control module or connecting wiring following the discharge process in step 2. Use caution not to recharge your body with static electricity; (i.e do not move or shuffle your feet, do not touch ungrounded objects, etc.). If you come in contact with an ungrounded object, repeat step 2 before touching control or wires.
- 4. Discharge your body to ground before removing a new control from its container. Follow steps 1 through 3 if installing the control on a furnace. Return any old or new controls to their containers before touching any ungrounded object. The primary limit control is located on the partition panel and de-energized.

# 14.2 Resetting From Lockout

Furnace lockout results when a furnace is unable to achieve ignition after three attempts. It is characterized by a non-functioning furnace, refer to the Troubleshooting chart (Tables 37 & 38) which describes what errors LED flashes correspond to. If the furnace is in "lockout" it will (or can be) reset in any of the following ways.

- Automatic reset. The integrated control module will automatically reset itself and attempt to resume normal operations following a one hour lockout period.
- Manual power interruption. Interrupt 115 volt power to the furnace for 1 -20 seconds.
- 3. Manual thermostat cycle. Lower the thermostat so that there is no longer a call for heat for 1 20 sec.



If the condition which originally caused the lockout still exists, the control will return to lockout. Refer to the Troubleshooting Chart (Tables 37 & 38) on the following page for aid in determining the cause.



### WARNING

# Fire, explosion and asphyxiation hazard!

Installation and service must be performed by a qualified service agency or the gas supplier.

# 14.3 Troubleshooting Chart

Refer to the troubleshooting chart on the following pages for assistance in determining the source of unit operational problems. Refer to the LED display to assist in troubleshooting the unit. (See Tables 37 & 38).



Symptoms of Abnormal Operation	Fault Code	Fault Description(s)	Possible Reason	Corrective Action	Cautions And Notes
Furnace fails to operate	None or FO	No 115 volt power to furnace, or no 24 volt power to integrated control module Blown fuse or circuit breaker Integrated control module has an internal fault	Door switch open, or 24 volt wires improperly connected or loose. Blown fuse or circuit breaker Integrated control module has an internal fault	Assure 115 and 24 volt power to furnace's integrated control module.     Check integrated control module's fuse (3A). Replace if necessary.     Check for possible shorts in 115 and 24 volt circuits. Repair as necessary OR replace bad integrated control module.	Turn power OFF prior to repair.  Replace integrated control module's fuse with 3A automotive fuse.  Read precautions in Electrostatic Discharge section of manual.
Furnace fails to operate	FE	Flame sensed     with gas valve off	Short to ground in flame sense circuit.	Correct short at flame sensor or in flame sensor wiring	Turn power OFF prior to repair.
Furnace fails to operate	E1	Pressure switch closed with inducer off	Induced draft blower pressure switch contacts "stuck".     Shorts in pressure switch circuit.	Replace induced draft blower's pressure switch.     Repair short.	Turn power OFF prior to repair.  Replace pressure switch with proper replacement part.
Induced draft blower runs continuously with no further furnace operation.	E2 E4 E3	Low fire pressure switch open with inducer on     Pressure switch cycle lockout     High fire pressure switch open with high inducer on	Pressure switch hose blocked, pinched or connected improperly, blocked flue, or weak induced draft blower.  Incorrect pressure switch setpoint or malfunctioning switch contacts.  Loose or improperly connected wiring.	Inspect pressure switch hose.     Repair if necessary. Inspect flue for blockage, proper length, elbows, and termination.     Replace pressure switch.     Tighten or correct wiring connection.	Turn power OFF prior to repair. Replace pressure switch with proper replacement part.
Furnace fails to operate.	E5 E6	Limit/Rollout switch open less than 5 mins Limit/Rollout switch open more than 15 mins Limit/Rollout switch open from 5 to 15 mins	Faulty chamber limit switch or fan mounted limit switch.  Insufficient conditioned air over the heat exchanger. Blocked filters, restrictive ductwork, improper circulator blower speed or failed circulator blower  Misaligned burners, blocked flue, or failed induced draft blower.  Faulty rollout switch - resettable.  Faulty inducer.  Loose or improperly connected wiring.	1. Check chamber limit switch or fan mounted limit switch. Replace if necessary.  2. Check filters and ductwork for blockage. Clean filters or remove obstruction. Check circulator blower speed and performance. Correct speed or replace blower if necessary.  3. Check burners for proper alignment. Check flue and air inlet piping for blockage, proper length, elbows and termination. Correct as necessary.  4. Check rollout switch - resettable. Replace if necessary.  5. Check induced draft blower for proper performance. Replace if necessary.  6. Tighten or correct wiring connection.	Turn power OFF prior to repair. Replace pressure switch with proper replacement part.

Table 37 Troubleshooting Chart



Symptoms of Abnormal Operation	Fault Code	Fault Description(s)	Possible Reason	Corrective Action	Cautions And Notes
Furnace fails to operate	E7 E8	Lockout due to failed ignition     Lockout due to too many flame dropouts	The gas valve switched off Iginitor failure Orifices are blocked/clogged Flame sensor dirty or broken Furnace improperly grounded Manifold gas pressure does not meet the requirement Inlet gas pressure does not meet the requirement	<ol> <li>Turn the gas valve switch to "On"</li> <li>Replace ignitor</li> <li>Remove the blockage</li> <li>Clean with steel wool.or replace the flame sensor.</li> <li>Properly ground the wire</li> <li>Adjust the gas valve. Replace the gas valve.</li> <li>Check incoming gas supply quality. Adjust the inlet gas pressure to meet requirement on nameplate.</li> </ol>	Turn power OFF prior to repair.
Furnace fails to operate	PR	Incorrect     line voltage     polarity	Wrong L1/L2 connection	Correct the wire connection	Turn power OFF prior to repair.
Furnace fails to operate	BE	Control failure	Control module failure	Replace control module	Turn power OFF prior to repair.
Abnormal Thermostat Signals	nL	Abnormal     T-stat signals	Thermostat wiring issue Thermostat failure	Correct the wire connection     Replace thermostat	• -
Abnormal furnace operation	FL	Low flame sense current	Flame sensor is coated/oxidized Flame sensor is incorrectly positioned in the burner flame. Lazy burner flame due to improper gas pressure or combustion air.	<ol> <li>Clean/sand flame sensor with steel wool.</li> <li>Inspect for proper sensor alignment.</li> <li>Compare current gas pressure to rating plate info. Adjust as needed.</li> </ol>	Turn power OFF prior to repair.  Clean flame sensor with steel wool.  See Section 8 for piping details.  See rating plate for proper gas pressure.

Table 38 Troubleshooting Chart

# **Online Help Resources**

Alternatively, please visit our Service & Support webpage to find FAQs, videos, service bulletins, and more; <a href="www.boschheatingcooling.com/service">www.boschheatingcooling.com/service</a> or use your cellphone to scan the code below.




Figure 64



# 15 Service and Maintenance Procedures



# **WARNING**

# Electrical shock, fire or explosion hazard!

Improper servicing could result in dangerous operation, serious injury, death or property damage.

- Before servicing, disconnect all electrical power to furnace.
- · When servicing controls, label all wires prior to
- disconnecting. Reconnect wires correctly.
- · Verify proper operation after servicing.



### **WARNING**

### Fire, explosion or carbon monoxide poisoning hazard!

Failure to replace with proper control could result in fire, explosion or carbon monoxide poisoning.

Replace ONLY with the same model number or as specified by the manufacturer.

This appliance uses a NEGATIVE PRESSURE REGULATED gas control.

# 15.1 Annual Inspection

The furnace must be inspected by a qualified installer or service agency at least once per year. Inspect the furnace at the beginning of the heating season. This will ensure that all furnace components are in proper working order and that the heating system functions appropriately. Pay particular attention to the following items. Repair or service as necessary.

- All flue gas carrying areas external to the furnace (i.e. chimney, vent connector, vent pipe) are clear and free of obstructions.
- b. Check for any loose wiring, and correct as needed.
- Inspect heat exchangers and blowers for corrosion, deterioration, or deposits of debris. Remove any obstructions.
- The vent connector is in place, slopes upward and is physically sound without holes or excessive corrosion.
- The return-air duct connection(s) is physically sound, is sealed to the furnace cabinet, and terminates outside the space containing the furnace.
- f. The physical support of the furnace is sound without sagging, cracks, gaps, etc. around the base so as to provide a seal between the support and the base.
- g. There are no obvious signs of deterioration of the furnace.
- h. The pilot and burner flames are in good adjustment (by comparison with pictorial sketches or drawings of the main burner flame and, if applicable, the pilot burner flame, refer to the Installation, Operation, and Maintenance Manual for more information).
- Check the condensate drain and trap for leaks and cracks. Fill the trap with water. Clean the drain and trap. The trap must be filled with water and the drain and trap should be cleaned.

### 15.2 Filters

A return air filter is not supplied with this furnace; however, there must be a means of filtering the return air. The installer must supply filter(s) at the time of installation.

#### Filter maintenance

Improper filter maintenance is the most common cause of inadequate heating or cooling performance. Clean permanent filter or replace disposable filter once a month or more frequently as required. When replacing a filter, it must be replaced with a filter of the same type and size.

Become familiar with filter location and procedures for removal, cleaning and replacing them. If help is needed, contact the installer of the furnace or a qualified service person.

#### Filter removal

Depending on the installation, differing filter arrangements can be applied. A media air filter or electronic air cleaner can be used as an alternate filter.

Follow the filter sizes given in the Recommended Minimum Filter size (Table 3) to ensure proper unit performance.

For further details, see your distributor.

### Upright filter removal

To remove filters from an external filter rack in an upright upflow installation, follow the directions provided with external filter rack kit.

Clean, wash and dry a permanent filter. When using a permanent filter, both sides should be sprayed with a dust adhesive as recommended on the adhesive container. Spray adhesives for use with permanent filters can be found at some hardware stores. BE SURE AIRFLOW DIRECTION ARROW POINTS TOWARDS THE BLOWER

Inspect filter. If your dirty filter is the disposable type, replace dirty filter with the same type and size filter. If your dirty filter is a permanent filter, clean as follows:

- Clean, wash, and dry a permanent filter. When using a permanent filter, both sides should be sprayed with a dust adhesive as recommended on the adhesive container.
- If badly torn or uncleanable, these filters must be replaced by equal size
  permanent, high velocity filters. Throwaway filters must not be used as
  replacement for permanent filters.

### 15.3 Induced Draft Blower And Indoor Blower Motors

The bearings in the induced draft blower and circulator blower motors are permanently lubricated by the manufacturer. No further lubrication is required. Check motor windings for accumulation of dust which may cause overheating. Clean as necessary.

# 15.4 Flame Sensor (Qualified Service Technicians Only)

Under some conditions the fuel or air supply can create a nearly invisible coating on the flame sensor. This coating acts as an insulator causing a drop in the flame sense signal. If the flame sense signal drops too low, the furnace will not sense the flame and will lock out. The flame sensor should be carefully cleaned by a qualified service technician using emery cloth or steel wool. Following cleaning, the flame sense signal should be 0.5 to 6 microamps at 115 volts.



# 15.5 Ignitor (Qualified Service Technicians Only)

If the ignitor and the surrounding air are at about 70°F and theignitor wires are not connected to any other electrical components. the resistance of the ignitor should not exceed 200 ohms. If it does, the ignitor should be replaced.

### 15.6 Burners



# WARNING

### Fire, explosion, electrical shock or carbon monoxide poisoning hazard!

To avoid personal injury or death. Do not remove any internal compartment covers or attempt any adjustment. Electrical components are contained in both compartments. Contact a qualified service agent at once if an abnormal flame appearance should develop.

Periodically during the heating season, perform a visual check of the burner flames. Turn the furnace on at the thermostat. Wait a few minutes since any dislodged dust will alter the normal flame appearance. Flames should be stable, quiet, soft and blue with slightly orange tips. They should not be yellow. They should extend directly outward from the burner ports without curling downward, floating or lifting off the ports. See Figure 63. Contact a qualified service agent at once if an abnormal flame appearance should develop or the burners have a heavy accumulation of soot and carbon.



### **WARNING**

### Personal injury!

Only a qualified contractor, installer or service agency can clean the burners.

# 15.7 Inspecting the Heat Exchanger (Qualified Service Technicians Only)

### NOTICE

# Product damage!

If the heat exchangers get a heavy accumulation of soot and carbon, they must be replaced rather than cleaning them. A heavy build-up of soot and carbon indicates that a problem exists which needs to be corrected, such as improper adjustment of manifold pressure, insufficient or poor quality combustion air, incorrect size or damaged manifold orifice(s), improper gas, or a restricted heat exchanger. In these scenarios, the heat exchanger must be replaced.

Inspect the heat exchanger for excessive rust, cracks, or holes. Visual inspection is always best, but requires training and practice. There are tools (field supplied) available to assist, such as inspection cameras and dye penetration inspection systems. Inspect the metal flue for rust or holes, and make sure it's supported properly.

### 15.8 Condensate Drain

 Inspect all condensate drain tubes and condensate trap assembly for leaks and proper drainage.

# 15.9 Repair and Replacement Parts

- When ordering any of the listed functional parts, be sure to provide the furnace model and serial numbers with the order.
- Parts are available from your distributor.
- Flame sensors and ignitors are considered serviceable items.

# 16 Before Leaving Installation

- Cycle the furnace with the thermostat at least three times. Verify cooling (if applicable) and fan only operation.
- Review the manual with the homeowner and discuss proper furnace operation and maintenance.
- Leave literature packet near furnace.






Figure 65

# **COMPONENT IDENTIFICATION:**

- 1. Outlet Flue Vent
- 2. Flame Sensor
- 3. Chamber Limit Switch-Fixed
- 4. Condensate Overflow Switch
- 5. Inducer
- 6. Door Switch
- 7. Integrated Control Module
- 8. Blower
- 9. Transformer
- 10. Condensate Trap
- 11. Junction Box

- 12. Condensate Collector
- 13. Pressure Switch
- 14. Two-Stage Gas Valve
- 15. Hot Surface Ignitor
- 16. Gas Manifold
- 17. Air Inlet
- 18. Burner
- 19. Rollout Limit Switch
- 20. Blower Control Module

Please contact your local installer or dealer for replacement parts.

# 17 Wiring Diagram




Figure 66



NOTES:

United States and Canada Bosch Thermotechnology Corp. 65 Grove St. Watertown, MA 02472

Tel: 800-283-3787 www.bosch-homecomfort.us

BTC 772003301 C / 06.2025

Bosch Thermotechnology Corp. reserves the right to make changes without notice due to continuing engineering and technological advances.

Version Française

