


The antenna is used to transmit data to the cloud.  
Mount the antenna on the side that is away from a wall or building for the strongest signal strength.

### Where to Mount the Antenna

Mount antenna on top of Louver ③ on the left or right side of the control board access panel away from the wall.



### How to Clip the Antenna

